

## Uobičajene radnje sa telefonom

Stavljanje poziva na čekanje/preuzimanje poziva	Pritisnite <b>Čekanje</b> ili <b>Nastavi</b> .
Prenos poziva na novi broj	Izaberite <b>Opcije &gt; Prenesi</b> , unesite određeni broj, a zatim ponovo pritisnite <b>Opcije &gt; Prenesi</b> .
Ponovno biranje broja	Pritisnite  dva puta ili <b>Opcije &gt; PonBir</b> .
Započinjanje standardnog konferencijskog poziva	Izaberite <b>Opcije &gt; Konfer</b> . Okrenite broj, a zatim izaberite <b>Opcije &gt; Konfer</b> ponovo. Ponovite isti postupak za svaku osobu.
Prosleđivanje lokala	Izaberite <b>Opcije &gt; PrSve</b> . Unesite broj telefona na koji želite da prosledite sve pozive. Da biste otkazali, izaberite <b>Opcije &gt; PrSve</b> .
Korišćenje evidencije poziva	Izaberite <b>Katalog (Knjiga) &gt; Propušteni pozivi, Primljeni pozivi ili Pozvani brojevi</b> . Da biste birali broj, dodite do stavke na listi i pritisnite <b>Biraj</b> ili .
Premeštanje deljene linije između stonog i bežičnog telefona	Na telefonu sa aktivnim pozivom pritisnite <b>Čekanje</b> . Na drugom telefonu izaberite deljeni poziv i pritisnite <b>Nastavi</b> da biste preuzeli poziv.



Cisco, Cisco Systems, the Cisco logo, and the Cisco Systems logo are registered trademarks or trademarks of Cisco Systems, Inc. and/or its affiliates in the United States and certain other countries. All other trademarks mentioned in this document or Website are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (0705R)

© 2008 Cisco Systems, Inc. All rights reserved.

OL-17622-01



### KRATKE INFORMACIJE



## Cisco Unified Wireless IP telefon 7921G za Cisco Unified Communications Manager 7.0

Korišćenje telefona

Tasterske prečice i dugmad

Definicije softverskih tastera

Unos teksta

Ikone ekrana telefona

Uobičajene radnje sa telefonom

## Korišćenje telefona

Uključivanje/isključivanje telefona	Pritisnite i držite  sve dok se telefon ne uključi ili isključi.
Pristup funkcijama telefona	Pritisnite <b>Opcije</b> da biste dobili listu funkcija: <ul style="list-style-type: none"> <li>• Pritisnite taster sa brojem da biste došli do funkcije <i>ili</i></li> <li>• Dodite do funkcije i pritisnite .</li> </ul>
Pristupanje opcijama u glavnom meniju	Pritisnite strelicu za navigaciju da otvorite: <ul style="list-style-type: none"> <li>• Meni „Katalog“ (<b>Knjiga</b>)</li> <li>• Prikaz linije (<b>Telefon</b>)</li> <li>• Meni „Postavke“ (<b>Alatke</b>)</li> <li>• Meni „Usluge“ (<b>Svet</b>)</li> </ul> Pritisnite taster sa brojem da biste došli do opcija menija.
Pristupanje telefonskom imeniku	Pritisnite <b>Tel. imenik</b> ili <b>Katalog &gt; Telefonski imenik</b> .
Prilagođavanje osvetljaja ekrana	Izaberite <b>Postavke &gt; Postavke telefona &gt; Postavke ekrana</b> , a zatim izaberite <b>Osvetljaj ekrana</b> . Pritisnite  ili , a zatim pritisnite <b>Sačuvaj</b> .

## Tasterske prečice i dugmad


Naizmenično uključivanje i isključivanje vibracije i tona zvona	Pritisnite i držite .
Pristup govornim porukama	Pritisnite i držite .
Podešavanje jačine tona zvona, tona u slušalici ili u zvučniku	Pritisnite  nagore ili nadole.
Prigušivanje/vraćanje zvuka na telefonu	Pritisnite .
Prelazak sa zvučnika na slušalicu i obrnuto	Pritisnite i držite .
Zaključavanje tastature	Pritisnite i držite .
Otključavanje tastature	Pritisnite <b>Otključaj</b> , a zatim <b>U redu</b> .

## Definicije softverskih tastera

<b>DirPren</b>	Prenos dva poziva jednog drugome
<b>DodSebe</b>	Dodavanje sebe u poziv na deljenoj liniji
<b>GJaviSe</b>	Odgovaranje na poziv koji zvoni u drugoj grupi ili na drugoj liniji
<b>HLog</b>	Prijavlјivanje ili odјavlјivanje iz svoje hunt grupe
<b>IDZP</b>	Prijavlјivanje sumnjivih poziva
<b>JaviSe</b>	Odgovor na poziv u svojoj grupi
<b>Konfer</b>	Kreiranje konferencijskog poziva
<b>MeetMe</b>	Uspostavlјanje „Meet-Me“ konferencije
<b>NeUzn</b>	Uključivanje/isključivanje funkcije „Ne uznemiravaj“ (NeUzn)
<b>Park</b>	Skladištenje aktivnog poziva pomoću opcije parkiranja poziva
<b>Poruka</b>	Pristup glasovnoj pošti
<b>Pren.</b>	Prenos poziva
<b>PridrSe</b>	Spajanje više poziva na jednoj liniji da bi se uspostavila konferencija
<b>PrimObav</b>	Primanje obaveštenja kad lokal koji je zauzet postane dostupan
<b>PrSve</b>	Podešavanje/otkazivanje prosleđivanja poziva
<b>QRT</b>	Prosleđivanje problema vezanih za pozive administratoru sistema
<b>SkrBir</b>	Pozivanje korišćenjem broja indeksa brzog biranja
<b>Tel. imenik</b>	Otvaranje telefonskog imenika
<b>tSkreni</b>	Slanje poziva u sistem za razmenu glasovnih poruka
<b>Učesnici</b>	Pregled učesnika konferencije
<b>Ukloni</b>	Uklanjanje učesnika konferencije
<b>UklPUč</b>	Odbacivanje poslednjeg učesnika dodatog konferencijskom pozivu
<b>UredBr</b>	Uređivanje broja u evidenciji poziva


## Unos teksta

**Znak** – pritisnite taster jednom ili više puta.


**Razmak** – pritisnite .


**Broj** – pritisnite taster sa brojem.

**Simbol** – pritisnite ove tastere:

 da biste uneli \* + - / = \ : ;

 da biste uneli **razmak** , . ‘ “ | \_ ~ ’















 da biste uneli # ? ( ) [ ] { }

 da biste uneli ! @ < > \$ % ^ &

## Ikone ekrana telefona

### Stanja linije i poziva

	Podignuta slušalica
	Uspostavljena veza
	Poziv stavljen na čekanje
	Prosleđivanje poziva omogućeno
	Deljena linija se koristi
	Dolazeći poziv ili BLF nadgledana linija zvoni (BLF JaviSe)
	BLF nadgledana linija se koristi
	BLF nadgledana linija neaktivna
	BLF nadgledana linija u stanju „Ne uznemiravaj“
	Brzo biranje, evidencija poziva ili lista kataloga (BLF status nepoznat)
	Interfonska linija u neaktivnom stanju
	Interfonska linija u jednosmernom audio pozivu

	Interfonska linija u dvosmernom audio pozivu
<b>Funkcije linije</b>	
	Telefonska linija
	URL adresa usluga
	Glasovna poruka
<b>Ostale funkcije</b>	
	Prigušenje tona uključeno
	Slušalica aktivna
	Režim zvučnika aktivan
	Zvono isključeno (nečujni režim)
	Zvono i vibracija uključeni
	Samo vibracija uključena
	Aplikacija aktivna
	Status radio signala
	Nema radio signala
	Status punjenja baterije
	Punjač za radnu površinu priključen
	Punjač za radnu površinu priključen sa isključenim zvonom (nečujni režim)
	Tastatura zaključana
	Poslovni broj za kontakt
	Kućni broj za kontakt
	Broj mobilnog telefona za kontakt
	Ostali brojevi za kontakt