



CLI COMMAND SUMMARY BY MODE

AppNav Controller Group Configuration Mode Commands

- (config-scg) appnav-controller [3-903](#)
- (config-scg) description [3-904](#)

Class Map Configuration Mode Commands

- (config) class-map [3-580](#)
- (config-cmap) description [3-927](#)
- (config-cmap) match peer [3-928](#)
- (config-cmap) match protocol [3-929](#)
- (config-cmap) match tcp [3-931](#)

Configuration Mode Commands

- (config) aaa accounting [3-522](#)
- (config) aaa authorization commands [3-525](#)
- (config) accelerator cifs [3-526](#)
- (config) accelerator cifs preposition [3-528](#)
- (config) accelerator epm [3-530](#)
- (config) accelerator http [3-531](#)
- (config) accelerator ica [3-534](#)
- (config) accelerator mapi [3-536](#)
- (config) accelerator nfs [3-538](#)
- (config) accelerator smb [3-539](#)
- (config) accelerator ssl [3-542](#)
- (config) accelerator video [3-544](#)
- (config) accelerator windows-print [3-546](#)
- (config) alarm overload-detect [3-547](#)
- (config) asset [3-549](#)
- (config) authentication configuration [3-550](#)

- (config) authentication content-request [3-555](#)
- (config) authentication fail-over [3-559](#)
- (config) authentication login [3-561](#)
- (config) auto-discovery [3-568](#)
- (config) auto-register [3-569](#)
- (config) banner [3-571](#)
- (config) bridge [3-574](#)
- (config) cdp [3-577](#)
- (config) central-manager [3-578](#)
- (config) clock [3-582](#)
- (config) cms [3-586](#)
- (config) crypto pki [3-589](#)
- (config) crypto ssl [3-591](#)
- (config) device mode [3-593](#)
- (config) directed-mode [3-595](#)
- (config) disk disk-name [3-596](#)
- (config) disk encrypt [3-598](#)
- (config) disk error-handling [3-599](#)
- (config) disk logical shutdown [3-600](#)
- (config) disk object-cache extend [3-601](#)
- (config) dre [3-602](#)
- (config) end [3-603](#)
- (config) exec-timeout [3-604](#)
- (config) exit [3-605](#)
- (config) flow monitor [3-606](#)
- (config) help [3-607](#)
- (config) hostname [3-609](#)
- (config) inetd [3-611](#)
- (config) inline [3-612](#)
- (config) inline vlan-id-connection-check [3-613](#)
- (config) interception [3-614](#)
- (config) interception-method [3-616](#)
- (config) interface bvi [3-618](#)

- (config) interface GigabitEthernet [3-620](#)
- (config) interface InlineGroup [3-625](#)
- (config) interface PortChannel [3-628](#)
- (config) interface standby [3-630](#)
- (config) interface TenGigabitEthernet [3-632](#)
- (config) interface virtual [3-636](#)
- (config) ip [3-639](#)
- (config) ip access-list [3-642](#)
- (config) ip icmp rate-limit unreachable [3-645](#)
- (config) ip unreachable df [3-647](#)
- (config) kerberos [3-648](#)
- (config) kernel kdb [3-650](#)
- (config) kernel kdump [3-652](#)
- (config) line [3-653](#)
- (config) logging console [3-654](#)
- (config) logging disk [3-656](#)
- (config) logging facility [3-658](#)
- (config) logging host [3-660](#)
- (config) ntp [3-662](#)
- (config) peer [3-664](#)
- (config) policy-map [3-665](#)
- (config) port-channel [3-667](#)
- (config) primary-interface [3-668](#)
- (config) radius-server [3-670](#)
- (config) service-insertion [3-672](#)
- (config) service-policy [3-675](#)
- (config) smb-conf [3-677](#)
- (config) snmp-server access-list [3-680](#)
- (config) snmp-server community [3-681](#)
- (config) snmp-server contact [3-683](#)
- (config) snmp-server enable traps [3-684](#)
- (config) snmp-server group [3-687](#)
- (config) snmp-server host [3-689](#)
- (config) snmp-server location [3-691](#)
- (config) snmp-server mib [3-692](#)
- (config) snmp-server notify inform [3-694](#)
- (config) snmp-server trap-source [3-695](#)
- (config) snmp-server user [3-697](#)
- (config) snmp-server view [3-699](#)
- (config) sshd [3-700](#)
- (config) ssh-key-generate [3-703](#)
- (config) stats-collector logging [3-704](#)
- (config) system jumbomtu [3-705](#)
- (config) tacacs [3-706](#)
- (config) tcp [3-709](#)
- (config) telnet enable [3-711](#)
- (config) tfo exception [3-712](#)
- (config) tfo optimize [3-713](#)
- (config) tfo tcp adaptive-buffer-sizing [3-714](#)
- (config) tfo tcp keepalive [3-715](#)
- (config) tfo tcp optimized-mss [3-716](#)
- (config) tfo tcp optimized-receive-buffer [3-717](#)
- (config) tfo tcp optimized-send-buffer [3-718](#)
- (config) tfo tcp original-mss [3-719](#)
- (config) tfo tcp original-receive-buffer [3-720](#)
- (config) tfo tcp original-send-buffer [3-721](#)
- (config) threshold-monitor [3-722](#)
- (config) transaction-logs [3-724](#)
- (config) username [3-727](#)
- (config) virtual-blade [3-729](#)
- (config) vn-service vpath [3-731](#)
- (config) wccp access-list [3-732](#)
- (config) wccp flow-redirect [3-734](#)
- (config) wccp router-list [3-736](#)
- (config) wccp shutdown [3-738](#)
- (config) wccp tcp-promiscuous service-pair [3-740](#)
- (config) windows-domain [3-742](#)

EXEC Mode Commands

- authentication strict-password-policy [3-566](#)
- cd [3-4](#)
- clear arp-cache [3-5](#)
- clear bmc [3-6](#)
- clear cache [3-7](#)
- clear cdp [3-9](#)
- clear cifs msg-signing-servers [3-10](#)
- clear connection [3-11](#)

clear dre [3-12](#)
clear ip [3-13](#)
clear license [3-14](#)
clear logging [3-15](#)
clear service-policy [3-16](#)
clear statistics [3-17](#)
clear statistics accelerator [3-19](#)
clear statistics connection [3-20](#)
clear statistics vn-service vpath [3-22, 3-23](#)
clear transaction-log [3-24](#)
clear users [3-25](#)
clear windows-domain [3-27](#)
clear windows-domain-log [3-28](#)
clock [3-29](#)
cms [3-30](#)
cms secure-store [3-33](#)
configure [3-36](#)
copy cdrom [3-37](#)
copy cdrom wow-recovery [3-38](#)
copy compactflash [3-39](#)
copy disk [3-40](#)
copy ftp [3-41](#)
copy http [3-44](#)
copy monitoring-log [3-46](#)
copy running-config [3-47](#)
copy startup-config [3-49](#)
copy sysreport [3-50](#)
copy system-status [3-52](#)
copy tech-support [3-53](#)
copy tftp [3-54](#)
cpfile [3-57](#)
crypto delete [3-58](#)
crypto export [3-59](#)
crypto generate [3-61](#)
crypto import [3-63](#)
crypto pki [3-65](#)
debug aaa accounting [3-66](#)
debug accelerator [3-70](#)
debug all [3-76](#)
debug appnav-controller connection [3-78](#)
debug authentication [3-80](#)
debug auto-discovery [3-82](#)
debug buf [3-84](#)
debug cdp [3-86](#)
debug cli [3-88](#)
debug cmm [3-90](#)
debug cms [3-92](#)
debug connection [3-94](#)
debug controllers [3-96](#)
debug dataserver [3-98](#)
debug dhcp [3-100](#)
debug directed-mode [3-102](#)
debug dre [3-104](#)
debug egress-method [3-106](#)
debug encryption-service [3-108](#)
debug fda [3-110](#)
debug fdm [3-112](#)
debug filtering [3-114](#)
debug flow [3-116](#)
debug generic-gre [3-118](#)
debug hw-raid [3-120](#)
debug imd [3-122](#)
debug inline [3-124](#)
debug logging [3-128](#)
debug monapi [3-126, 3-130](#)
debug nplogd [3-132](#)
debug ntp [3-134](#)
debug punt [3-136](#)
debug rbcg [3-138](#)
debug rmd [3-140](#)
debug rpc [3-142](#)
debug service-insertion [3-144](#)
debug service-policy [3-146](#)
debug snmp [3-148](#)
debug standby [3-150](#)
debug statistics [3-152](#)
debug synq [3-154](#)
debug tfo [3-156](#)

debug translog [3-158](#)
 debug wafs [3-160](#)
 debug wecp [3-162](#)
 delfile [3-164](#)
 deltree [3-165](#)
 dir [3-166](#)
 disable [3-168](#)
 disk [3-169](#)
 dnslookup [3-172](#)
 enable [3-173](#)
 exit [3-174](#)
 find-pattern [3-175](#)
 help [3-177](#)
 install [3-178](#)
 less [3-180](#)
 license add [3-181](#)
 lls [3-182](#)
 ls [3-183](#)
 lsub [3-185](#)
 mkdir [3-186](#)
 mkfile [3-187](#)
 monitor appnav-controller traffic [3-188](#)
 ntpdate [3-189](#)
 packet-capture [3-190](#)
 ping [3-192](#)
 pwd [3-193](#)
 reload [3-194](#)
 rename [3-195](#)
 restore [3-196](#)
 rmdir [3-200](#)
 scp [3-201](#)
 script [3-203](#)
 setup [3-204](#)
 show aaa accounting [3-205](#)
 show aaa authorization [3-207](#)
 show accelerator [3-208](#)
 show alarms [3-212](#)
 show appnav-controller flow-distribution [3-215](#)
 show arp [3-217](#)
 show authentication [3-218](#)
 show auto-discovery [3-220](#)
 show auto-register [3-221](#)
 show banner [3-222](#)
 show bmc [3-223](#)
 show bridge [3-225](#)
 show cache http-metadatabase [3-227](#)
 show cdp [3-229](#)
 show cifs [3-235](#)
 show class-map [3-237](#)
 show clock [3-239](#)
 show cms [3-241](#)
 show cms secure-store [3-244](#)
 show crypto [3-246](#)
 show debugging [3-248](#)
 show device-id [3-249](#)
 show device-mode [3-250](#)
 show directed-mode [3-252](#)
 show disks [3-253](#)
 show dre [3-260](#)
 show filtering list [3-261](#)
 show flash [3-263](#)
 show hardware [3-264](#)
 show hosts [3-267](#)
 show inetd [3-268](#)
 show interception-method [3-269](#)
 show interface [3-270](#)
 show inventory [3-274](#)
 show ip access-list [3-275](#)
 show ip routes [3-277](#)
 show kdump [3-278](#)
 show kerberos [3-279](#)
 show key-manager [3-280](#)
 show license [3-281](#)
 show logging [3-282](#)
 show memory [3-283](#)
 show monitor [3-284](#)
 show ntp [3-285](#)
 show peer optimization [3-287](#)

show policy-map [3-288](#)
 show policy-sub-class [3-289](#)
 show processes [3-291](#)
 show radius-server [3-293](#)
 show reload [3-295](#)
 show running-config [3-296](#)
 show service-insertion [3-298](#)
 show service-policy [3-304](#)
 show services [3-307](#)
 show smb-conf [3-308](#)
 show snmp [3-310](#)
 show ssh [3-316](#)
 show startup-config [3-317](#)
 show statistics accelerator [3-319](#)
 show statistics aoim [3-356](#)
 show statistics application [3-360](#)
 show statistics appnav-controller [3-363](#)
 show statistics authentication [3-365](#)
 show statistics auto-discovery [3-366](#)
 show statistics cifs [3-369](#)
 show statistics class-default [3-371](#)
 show statistics class-map [3-372](#)
 show statistics connection [3-374](#)
 show statistics connection auto-discovery [3-378](#)
 show statistics connection closed [3-380](#)
 show statistics connection conn-id [3-383](#)
 show statistics connection egress-methods [3-386](#)
 show statistics connection optimized [3-390](#)
 show statistics connection pass-through [3-393](#)
 show statistics crypto ssl ciphers [3-395](#)
 show statistics datamover [3-396](#)
 show statistics directed-mode [3-398](#)
 show statistics dre [3-399](#)
 show statistics filtering [3-402](#)
 show statistics flow [3-405](#)
 show statistics generic-gre [3-408](#)
 show statistics icmp [3-409](#)
 show statistics ip [3-411](#)
 show statistics monitor appnav-controller traffic [3-414](#)
 show statistics netstat [3-416](#)
 show statistics pass-through [3-417](#)
 show statistics peer [3-419](#)
 show statistics policy-sub-class [3-422](#)
 show statistics punt [3-424](#)
 show statistics radius [3-425](#)
 show statistics service-insertion [3-427](#)
 show statistics services [3-428](#)
 show statistics sessions [3-429](#)
 show statistics snmp [3-430](#)
 show statistics synq [3-432](#)
 show statistics tacacs [3-433](#)
 show statistics tcp [3-435](#)
 show statistics tfo [3-439](#)
 show statistics udp [3-443](#)
 show statistics vn-service vpath [3-444](#)
 show statistics wccp [3-446](#)
 show statistics windows-domain [3-451](#)
 show statistics windows-print requests [3-453](#)
 show synq list [3-455](#)
 show sysfs volumes [3-456](#)
 show tacacs [3-457](#)
 show tcp [3-459](#)
 show tech-support [3-461](#)
 show telnet [3-464](#)
 show tfo tcp [3-465](#)
 show transaction-logging [3-467](#)
 show user [3-469](#)
 show users administrative [3-470](#)
 show version [3-472](#)
 show virtual-blade [3-473](#)
 show wccp [3-476](#)
 show windows-domain [3-483](#)
 shutdown [3-485](#)
 snmp trigger [3-488](#)
 ssh [3-492](#)
 tcpdump [3-493](#)

telnet [3-495](#)
terminal [3-496](#)
test [3-497](#)
tethered [3-500](#)
top [3-503](#)
traceroute [3-505](#)
transaction-log [3-506](#)
type [3-507](#)
type-tail [3-508](#)
virtual-blade [3-510](#)
vm [3-512](#)
waas-tcptrace [3-514](#)
whoami [3-516](#)
windows-domain [3-517](#)
write [3-520](#)

(config-if) half-duplex [3-761](#)
(config-if) inline [3-763](#)
(config-if) ip [3-765](#)
(config-if) ip access-group [3-767](#)
(config-if) load-interval [3-769](#)
(config-if) mtu [3-770](#)
(config-if) shutdown [3-771](#)
(config-if) standby [3-772](#)

Extended ACL Configuration Mode Commands

(config-ext-nacl) delete [3-788](#)
(config-ext-nacl) deny [3-789](#)
(config-ext-nacl) exit [3-794](#)
(config-ext-nacl) list [3-795](#)
(config-ext-nacl) move [3-796](#)
(config-ext-nacl) permit [3-797](#)

Interface Configuration Mode Commands

(config-if) autosense [3-747](#)
(config-if) bandwidth [3-748](#)
(config-if) bridge-group [3-750](#)
(config-if) cdp [3-752](#)
(config-if) channel-group [3-753](#)
(config-if) description [3-754](#)
(config-if) encapsulation dot1Q [3-755](#)
(config-if) exit [3-756](#)
(config-if) failover timeout [3-757](#)
(config-if) full-duplex [3-759](#)

PKI Certificate Authority Configuration Mode Commands

(config-ca) ca-certificate [3-839](#)
(config-ca) description [3-840](#)
(config-ca) revocation-check [3-841](#)

PKI Global Settings Configuration Mode Commands

(config-pki-global-settings) oosp [3-844](#)
(config-pki-global-settings) revocation-check [3-845](#)

Policy Map Class Configuration Mode Commands

(config-pmap-c) distribute [3-939](#)
(config-pmap-c) monitor-load [3-940](#)
(config-pmap-c) optimize [3-942](#)
(config-pmap-c) pass-through [3-944](#)
(config-pmap-c) service-policy [3-946](#)
(config-pmap-c) set ip dscp [3-947](#)

Policy Map Configuration Mode Commands

(config-pmap) class [3-935](#)
(config-pmap) description [3-936](#)

Preposition Configuration Mode Commands

- (config-preposition) credentials [3-805](#)
- (config-preposition) dscp [3-806](#)
- (config-preposition) duration [3-807](#)
- (config-preposition) enable [3-808](#)
- (config-preposition) ignore-hidden-dir [3-809](#)
- (config-preposition) max-cache [3-810](#)
- (config-preposition) max-file-size [3-811](#)
- (config-preposition) min-file-size [3-812](#)
- (config-preposition) name [3-813](#)
- (config-preposition) recursive [3-815](#)
- (config-preposition) root [3-816](#)
- (config-preposition) scan-type [3-814](#), [3-817](#)
- (config-preposition) schedule [3-818](#)
- (config-preposition) server [3-820](#)

Service Context Configuration Mode Commands

- (config-scx) appnav-controller-group [3-917](#)
- (config-scx) authentication [3-918](#)
- (config-scx) description [3-919](#)
- (config-scx) enable [3-920](#)
- (config-scx) service-node-group [3-922](#)
- (config-scx) service-policy [3-923](#)

Service Node Configuration Mode Commands

- (config-sn) authentication [3-911](#)
- (config-sn) description [3-912](#)
- (config-sn) enable [3-913](#)
- (config-sn) shutdown [3-914](#)

Service Node Group Configuration Mode Commands

- (config-sng) description [3-907](#)
- (config-sng) service-node [3-908](#)

SSL Accelerated Service Configuration Mode Commands

- (config-ssl-accelerated) cipher-list [3-849](#)
- (config-ssl-accelerated) client-cert-verify [3-850](#)
- (config-ssl-accelerated) client-version-rollback-check [3-851](#)
- (config-ssl-accelerated) description [3-852](#)
- (config-ssl-accelerated) inservice [3-853](#)
- (config-ssl-accelerated) server-cert-key [3-854](#)
- (config-ssl-accelerated) server-cert-verify [3-855](#)
- (config-ssl-accelerated) server-domain [3-856](#)
- (config-ssl-accelerated) server-ip [3-857](#)
- (config-ssl-accelerated) server-name [3-858](#)
- (config-ssl-accelerated) version [3-859](#)

SSL Cipher List Configuration Mode Commands

- (config-cipher-list) cipher [3-862](#)

SSL Global Service Configuration Mode Commands

- (config-ssl-global) cipher-list [3-867](#)
- (config-ssl-global) machine-cert-key [3-868](#)
- (config-ssl-global) version [3-869](#)

SSL Host Peering Service Configuration Mode Commands

- (config-ssl-peering) cipher-list [3-873](#)
- (config-ssl-peering) peer-cert-verify [3-874](#)

(config-ssl-peering) version [3-875](#)

(config-wccp-service) redirect-method [3-894](#)

(config-wccp-service) router-list-num [3-896](#)

(config-wccp-service) weight [3-898](#)

SSL Management Service Configuration Mode Commands

(config-ssl-mgmt) cipher-list [3-879](#)

(config-ssl-mgmt) peer-cert-verify [3-880](#)

(config-ssl-mgmt) version [3-881](#)

Standard ACL Configuration Mode Commands

(config-std-nacl) delete [3-777](#)

(config-std-nacl) deny [3-778](#)

(config-std-nacl) exit [3-780](#)

(config-std-nacl) list [3-781](#)

(config-std-nacl) move [3-782](#)

(config-std-nacl) permit [3-783](#)

Virtual Blade Configuration Mode Commands

(config-vb) autostart [3-823](#)

(config-vb) boot [3-824](#)

(config-vb) cpu-list [3-826](#)

(config-vb) description [3-828, 3-829](#)

(config-vb) disk [3-832](#)

(config-vb) interface [3-834](#)

(config-vb) memory [3-835](#)

(config-vb) vnc [3-836](#)

WCCP Configuration Mode Commands

(config-wccp-service) assignment-method [3-885](#)

(config-wccp-service) egress-method [3-887](#)

(config-wccp-service) enable [3-889](#)

(config-wccp-service) exit [3-890](#)

(config-wccp-service) failure-detection [3-891](#)

(config-wccp-service) password [3-893](#)