



# Preface

---

This preface includes the following sections:

- [Audience, page i](#)
- [Organization, page i](#)
- [Related Documentation, page i](#)
- [Obtain Documentation and Submit a Service Request, page ii](#)

## Audience

This troubleshooting guide is designed for users who are responsible for troubleshooting issues that arise on the Firepower 9300.

## Organization

This reference guide is organized into the following parts and chapters:

- Cisco Firepower 9300 Faults
  - [Chapter 1, “Introduction to Cisco Firepower 9300 Faults”](#)
  - [Chapter 2, “Firepower 9300 Faults”](#)
  - [Chapter 3, “FSM Faults”](#)
  - [Chapter 4, “Troubleshooting Transient Faults”](#)
- Cisco Firepower 9300 SEL Messages
  - [Chapter 5, “Introduction to System Event Log Messages”](#)
  - [Chapter 6, “Baseboard Management Controller Messages”](#)

## Related Documentation

A roadmap that lists all documentation for the Cisco Firepower 9300 is available at the following URL:  
<http://www.cisco.com/go/firepower9300-docs>

# Obtain Documentation and Submit a Service Request

For information on obtaining documentation, using the Cisco Bug Search Tool (BST), submitting a service request, and gathering additional information, see [What's New in Cisco Product Documentation](#).

To receive new and revised Cisco technical content directly to your desktop, you can subscribe to the [What's New in Cisco Product Documentation RSS feed](#). The RSS feeds are a free service.