



## INDEX

---

### A

aaa accounting dot1x command [2-1](#)  
aaa authentication dot1x command [2-3](#)  
AAA methods [2-3](#)  
access control entries  
    See ACEs  
access control lists  
    See ACLs  
access groups  
    IP [2-133](#)  
    MAC, displaying [2-482](#)  
    matching for QoS classification [2-249](#)  
access list, IPv6 [2-196](#)  
access mode [2-640](#)  
access ports [2-640](#)  
ACEs [2-77](#), [2-288](#)  
ACLs  
    as match criteria for QoS classes [2-249](#)  
    deny [2-75](#)  
    displaying [2-364](#)  
    for non-IP protocols [2-227](#)  
    IP [2-133](#)  
    on Layer 2 interfaces [2-133](#)  
    permit [2-286](#)  
action command [2-5](#)  
address aliasing [2-269](#)  
aggregate policers  
    applying [2-299](#)  
    creating [2-295](#)  
    displaying [2-517](#)  
    QoS [2-297](#)  
aggregate-port learner [2-275](#)

alarm-contact command [2-7](#)  
alarm-contact status, displaying [2-396](#)  
allowed VLANs [2-656](#)  
archive download-sw command [2-9](#)  
archive tar command [2-12](#)  
archive upload-sw command [2-15](#)  
arp (boot loader) command [A-2](#)  
arp access-list command [2-17](#)  
attaching policy maps to interfaces [2-347](#)  
authorization state of controlled port [2-90](#)  
autonegotiation of duplex mode [2-101](#)

---

### B

backup interfaces  
    configuring [2-633](#)  
    displaying [2-418](#)  
bandwidth, configuring for QoS [2-19](#)  
bandwidth command [2-19](#)  
boot (boot loader) command [A-3](#)  
boot config-file command [2-22](#)  
boot enable-break command [2-23](#)  
boot helper command [2-24](#)  
boot helper-config file command [2-25](#)  
booting  
    Cisco IOS image [2-28](#)  
    displaying environment variables [2-369](#)  
    interrupting [2-23](#)  
    manually [2-26](#)

## boot loader

- accessing [A-1](#)

- booting

- Cisco IOS image [A-3](#)

- helper image [2-24](#)

- directories

- creating [A-18](#)

- displaying a list of [A-8](#)

- removing [A-22](#)

- displaying

- available commands [A-13](#)

- memory heap utilization [A-14](#)

- version [A-29](#)

- environment variables

- described [A-23](#)

- displaying settings [A-23](#)

- location of [A-24](#)

- setting [A-23](#)

- unsetting [A-27](#)

- files

- copying [A-6](#)

- deleting [A-7](#)

- displaying a list of [A-8](#)

- displaying the contents of [A-5, A-19, A-26](#)

- renaming [A-20](#)

- file system

- formatting [A-11](#)

- initializing flash [A-10](#)

- running a consistency check [A-12](#)

- prompt [A-1](#)

- resetting the system [A-21](#)

- boot manual command [2-26](#)

- boot private-config-file command [2-27](#)

- boot system command [2-28](#)

- BPDU filtering, for spanning tree [2-578, 2-616](#)

- BPDU guard, for spanning tree [2-580, 2-616](#)

- broadcast storm control [2-626](#)

- bundling characteristics, UNI [2-109](#)

- burst bytes, in QoS policers [2-290, 2-291, 2-295](#)

---

**C**

- cat (boot loader) command [A-5](#)

- CBWFQ, configuring [2-19](#)

- CDP, enabling protocol tunneling for [2-207](#)

- CFM [2-274](#)

- CFM as OAM protocol [2-274](#)

- channel-group command [2-29](#)

- channel-protocol command [2-33](#)

- child policy maps [2-349](#)

- class-based traffic shaping [2-362](#)

- class-based weighted fair queuing

- See CBWFQ

- class command [2-35](#)

- class-map command [2-37](#)

- class-map configuration mode [2-37](#)

- class maps

- creating [2-37](#)

- defining the match criteria [2-250](#)

- displaying [2-373](#)

- matching in [2-37](#)

- class of service

- See CoS

- clear ip arp inspection log command [2-39](#)

- clear ip arp inspection statistics command [2-40](#)

- clear ipc command [2-43](#)

- clear ipv6 dhcp conflict command [2-44](#)

- clear l2protocol-tunnel counters command [2-45](#)

- clear lacp command [2-46](#)

- clear logging onboard command [2-47](#)

- clear mac address-table command [2-48, 2-49](#)

- clear pagp command [2-50, 2-54](#)

- clear policer cpu uni-eni counters command [2-51](#)

- clear port-security command [2-52](#)

- clear spanning-tree counters command [2-55](#)

- clear spanning-tree detected-protocols command [2-56](#)

- clear vmps statistics command [2-58](#)

- command modes defined [1-1](#)

- committed information rate in QoS policers [2-289, 2-295](#)

- configuration files
    - password recovery disable considerations [A-1](#)
    - specifying the name [2-22, 2-27](#)
  - configuring multiple interfaces [2-129](#)
  - conform-action command [2-59](#)
  - control-plane policer [2-51](#)
  - control-plane policer information, displaying [2-518](#)
  - control-plane security [2-301](#)
  - control plane statistics, clearing [2-51](#)
  - copy (boot loader) command [A-6](#)
  - copy logging onboard module command [2-61](#)
  - CoS
    - as match criteria for QoS groups [2-250](#)
    - for QoS classification [2-351](#)
    - setting value in policy maps [2-351](#)
  - CoS value, assigning to Layer 2 protocol packets [2-210](#)
  - CPU ASIC statistics, displaying [2-374](#)
  - CPU protection policers, displaying [C-26](#)
  - cpu traffic qos [2-63](#)
- 
- D**
- DC power supply [2-310](#)
  - debug backup command [B-2](#)
  - debug dot1x command [B-3](#)
  - debug etherchannel command [B-4](#)
  - debug interface command [B-9](#)
  - debug ip dhcp snooping command [B-7](#)
  - debug ip igmp filter command [B-10](#)
  - debug ip igmp max-groups command [B-11](#)
  - debug ip igmp snooping command [B-12](#)
  - debug ip verify source packet command [B-8](#)
  - debug lacp command [B-13](#)
  - debug mac-notification command [B-14](#)
  - debug matm command [B-15](#)
  - debug matm move update command [B-16](#)
  - debug monitor command [B-17](#)
  - debug mvrdbg command [B-18](#)
  - debug nvram command [B-19](#)
  - debug pagp command [B-20](#)
  - debug platform acl command [B-21](#)
  - debug platform backup interface command [B-23](#)
  - debug platform cfm command [B-22](#)
  - debug platform cpu-queues command [B-24](#)
  - debug platform dot1x command [B-26](#)
  - debug platform etherchannel command [B-27](#)
  - debug platform forw-tcam command [B-28](#)
  - debug platform ip arp inspection command [B-29](#)
  - debug platform ipc command [B-38](#)
  - debug platform ip dhcp command [B-30](#)
  - debug platform ip igmp snooping command [B-31](#)
  - debug platform ip multicast command [B-33](#)
  - debug platform ip source-guard command [B-35](#)
  - debug platform led command [B-39](#)
  - debug platform matm command [B-40](#)
  - debug platform messaging application command [B-41](#)
  - debug platform phy command [B-42](#)
  - debug platform pm command [B-44](#)
  - debug platform policer cpu uni-eni command [B-46](#)
  - debug platform port-asic command [B-47](#)
  - debug platform port-security command [B-48](#)
  - debug platform qos-acl-tcam command [B-49](#)
  - debug platform qos-manager command [B-50](#)
  - debug platform remote-commands command [B-51](#)
  - debug platform rep command [B-52](#)
  - debug platform resource-manager command [B-53](#)
  - debug platform snmp command [B-54](#)
  - debug platform span command [B-55](#)
  - debug platform supervisor-asic command [B-56](#)
  - debug platform sw-bridge command [B-57](#)
  - debug platform tcam command [B-58](#)
  - debug platform udd command [B-60](#)
  - debug platform vlan command [B-61](#)
  - debug pm command [B-62](#)
  - debug port-security command [B-64](#)
  - debug qos-manager command [B-65](#)
  - debug spanning-tree bpdu command [B-68](#)
  - debug spanning-tree bpdu-opt command [B-69](#)

- debug spanning-tree command [B-66](#)
- debug spanning-tree mstp command [B-70](#)
- debug spanning-tree switch command [B-72](#)
- debug sw-vlan command [B-74](#)
- debug sw-vlan ifs command [B-75](#)
- debug sw-vlan notification command [B-76](#)
- debug udd command [B-78](#)
- debug vqpc command [B-80](#)
- default policer configuration
  - NNIs [C-29](#)
  - UNIs [C-27](#)
- define interface-range command [2-65](#)
- delete (boot loader) command [A-7](#)
- delete command [2-67](#)
- deny (ARP access-list configuration) command [2-68](#)
- deny (IPv6) command [2-70](#)
- deny command [2-75](#)
- detect mechanism, causes [2-102](#)
- DHCP snooping
  - accepting untrusted packets from edge switch [2-157](#)
  - enabling
    - on a VLAN [2-163](#)
    - option 82 [2-155, 2-157](#)
    - trust on an interface [2-161](#)
  - error recovery timer [2-104](#)
  - rate limiting [2-160](#)
- DHCP snooping binding database
  - binding file, configuring [2-153](#)
  - bindings
    - adding [2-151](#)
    - deleting [2-151](#)
    - displaying [2-439](#)
  - clearing database agent statistics [2-41](#)
  - database agent, configuring [2-153](#)
  - displaying
    - binding entries [2-439](#)
    - database agent status [2-441, 2-443](#)
  - renewing [2-325](#)
- diagnostic monitor command [2-78](#)
- diagnostic schedule test command [2-80](#)
- diagnostic start test command [2-82](#)
- differentiated service code point
  - See DSCP
- Digital Optical Monitoring
  - see DoM
- dir (boot loader) command [A-8](#)
- directories, deleting [2-67](#)
- DoM
  - displaying supported transceivers [2-430](#)
- domains, CFM [2-274](#)
- dot1x default command [2-84](#)
- dot1x host-mode command [2-85](#)
- dot1x initialize command [2-87](#)
- dot1x max-req command [2-88, 2-89](#)
- dot1x port-control command [2-90](#)
- dot1x re-authenticate command [2-92](#)
- dot1x reauthentication command [2-93](#)
- dot1x system-auth-control command [2-94](#)
- dot1x test eapol-capable command [2-95](#)
- dot1x test timeout command [2-96](#)
- dot1x timeout command [2-97](#)
- dot1x violation-mode command [2-99](#)
- dropping packets, with ACL matches [2-5](#)
- drop threshold, Layer 2 protocol tunneling [2-207](#)
- DSCP
  - as match criteria for QoS groups [2-251, 2-257](#)
  - for QoS traffic marking [2-353](#)
  - setting in policy maps [2-353](#)
- dual IPv4 and IPv6 templates [2-281](#)
- dual-purpose uplink ports, selecting the type [2-262](#)
- duplex command [2-100](#)
- dynamic-access ports
  - configuring [2-631](#)
  - restrictions [2-632](#)

- dynamic ARP inspection
  - ARP ACLs
    - apply to a VLAN [2-138](#)
    - define [2-17](#)
    - deny packets [2-68](#)
    - display [2-368](#)
    - permit packets [2-279](#)
  - clear
    - log buffer [2-39](#)
    - statistics [2-40](#)
  - display
    - ARP ACLs [2-368](#)
    - configuration and operating state [2-434](#)
    - log buffer [2-434](#)
    - statistics [2-434](#)
    - trust state and rate limit [2-434](#)
  - enable per VLAN [2-147](#)
  - error detection for [2-102](#)
  - error recovery timer [2-104](#)
  - log buffer
    - clear [2-39](#)
    - configure [2-142](#)
    - display [2-434](#)
  - rate-limit incoming ARP packets [2-140](#)
  - statistics
    - clear [2-40](#)
    - display [2-434](#)
  - trusted interface state [2-144](#)
  - type of packet logged [2-148](#)
  - validation checks [2-145](#)
- Dynamic Host Configuration Protocol (DHCP)
  - See DHCP snooping
- E-LMI
  - enabling [2-107](#)
  - mapping [2-109](#)
- environment variables, displaying [2-369](#)
- errdisable detect cause command [2-102](#)
- errdisable recovery command [2-104](#)
- error conditions, displaying [2-400](#)
- error disable detection [2-102](#)
- error-disabled interfaces, displaying [2-418](#)
- EtherChannel
  - assigning Ethernet interface to channel group [2-29](#)
  - creating port-channel logical interface [2-127](#)
  - debug EtherChannel/PAgP, display [B-4](#)
  - debug platform-specific events, display [B-27](#)
  - displaying [2-404](#)
  - enabling Layer 2 protocol tunneling for
    - LACP [2-208](#)
    - PAgP [2-208](#)
    - UDLD [2-208](#)
  - interface information, displaying [2-418](#)
  - LACP
    - clearing channel-group information [2-46](#)
    - debug messages, display [B-13](#)
    - displaying [2-469](#)
    - modes [2-29](#)
    - port priority for hot-standby ports [2-211](#)
    - restricting a protocol [2-33](#)
    - system priority [2-213](#)
  - load-distribution methods [2-306](#)

---

## E

- EAP-request/identity frame
  - maximum number to send [2-89](#)
  - response time before retransmitting [2-97](#)

## EtherChannel (continued)

## PAgP

- aggregate-port learner [2-275](#)
- clearing channel-group information [2-50](#)
- debug messages, display [B-20](#)
- displaying [2-513](#)
- error detection for [2-102](#)
- error recovery timer [2-104](#)
- learn method [2-275](#)
- modes [2-29](#)
- physical-port learner [2-275](#)
- priority of interface for transmitted traffic [2-277](#)

ethermet lmi ce command [2-107](#)

Ethernet controller, internal register display [2-376](#)

ethernet evc command [2-106](#)

ethernet lim global command [2-107](#)

ethernet lmi ce-vlan map command [2-109, 2-116](#)

ethernet lmi command [2-107](#)

## Ethernet Local Management Interface

See E-LMI

ethernet loopback interface configuration command [2-111](#)

ethernet loopback privileged EXEC command [2-114](#)

## Ethernet service

- debugging [B-5](#)
- displaying [2-409](#)

Ethernet service instance [2-343](#)

Ethernet service interfaces [2-412](#)

Ethernet statistics, collecting [2-339](#)

Ethernet UNI configuration [2-118](#)

ethernet uni id command [2-120](#)

## Ethernet virtual connections

See EVCs

EVC configuration mode [2-106](#)

EVCs [2-106](#)

- and VLANs [2-118](#)
- service instances [2-343](#)
- UNI counts [2-678](#)

## EVC service

- point-to-multipoint [2-678](#)
- point-to-point [2-678](#)

exceed-action command [2-121](#)

## extended-range VLANs

- and allowed VLAN list [2-656](#)
- configuring [2-684](#)

extended system ID for STP [2-586](#)

external alarms, configuring [2-7](#)

---

**F**

## failure logging data

- clearing [2-47](#)
- copying [2-61](#)

fan information, displaying [2-396](#)

files, deleting [2-67](#)

flash\_init (boot loader) command [A-10](#)

## Flex Links

- configuring [2-633](#)
- configuring preferred VLAN [2-635](#)
- displaying [2-418](#)

flowcontrol command [2-123](#)

format (boot loader) command [A-11](#)

forwarding packets, with ACL matches [2-5](#)

forwarding results, display [C-8](#)

frame forwarding information, displaying [C-8](#)

front-end controller counter and status information [C-10](#)

fsck (boot loader) command [A-12](#)

---

**G**

global configuration mode [1-2, 1-3](#)

**H**

- hardware ACL statistics [2-364](#)
- health-monitoring diagnostic testing [2-78](#)
- help (boot loader) command [A-13](#)
- host connection, port configuration [2-639](#)
- host ports, private VLANs [2-643](#)
- hw-module module logging onboard command [2-125](#)

**I**

- IEEE 802.1ag Connectivity Fault Management
  - See CFM
- IEEE 802.1Q trunk ports and native VLANs [2-689](#)
- IEEE 802.1Q tunnel ports
  - configuring [2-640](#)
  - displaying [2-392](#)
  - limitations [2-641](#)
- IEEE 802.1x
  - and switchport modes [2-641](#)
  - violation error recovery [2-104](#)
  - See also port-based authentication
- IGMP filters
  - applying [2-166](#)
  - debug messages, display [B-10](#)
- IGMP groups, setting maximum [2-168](#)
- IGMP maximum groups, debugging [B-11](#)
- IGMP profiles
  - creating [2-170](#)
  - displaying [2-446](#)
- IGMP snooping
  - adding ports as a static member of a group [2-185](#)
  - displaying [2-447, 2-451, 2-453](#)
  - enabling [2-172](#)
  - enabling the configurable-leave timer [2-174](#)
  - enabling the Immediate-Leave feature [2-182](#)
  - flooding query count [2-180](#)
  - interface topology change notification behavior [2-181](#)
  - multicast table [2-449](#)
  - IGMP snooping (continued)
    - querier [2-176](#)
    - query solicitation [2-180](#)
    - report suppression [2-178](#)
    - switch topology change notification behavior [2-180](#)
- images
  - See software images
- Immediate-Leave feature, MVR [2-271](#)
- immediate-leave processing [2-182](#)
- input policy maps
  - and ACL classification [2-249](#)
  - and aggregate policers [2-297](#)
  - commands not supported in [2-304](#)
  - configuration guidelines [2-304](#)
- interface command [2-131](#)
- interface configuration mode [1-2, 1-4](#)
- interface port-channel command [2-127](#)
- interface range command [2-129](#)
- interface-range macros [2-63, 2-65](#)
- interfaces
  - assigning Ethernet interface to channel group [2-29](#)
  - configuring [2-100](#)
  - configuring multiple [2-129](#)
  - creating port-channel logical [2-127](#)
  - debug messages, display [B-9](#)
  - disabling [2-563](#)
  - displaying the MAC address table [2-494](#)
  - restarting [2-563](#)
- interface speed, configuring [2-624](#)
- internal registers, displaying [2-376, 2-383, 2-387](#)
- Internet Group Management Protocol
  - See IGMP
- invalid GBIC
  - error detection for [2-102](#)
  - error recovery timer [2-104](#)
- ip address command [2-136](#)
- IP addresses, setting [2-136](#)
- IP address matching [2-247](#)
- ip arp inspection filter vlan command [2-138](#)

- ip arp inspection limit command [2-140](#)
  - ip arp inspection log-buffer command [2-142](#)
  - ip arp inspection trust command [2-144](#)
  - ip arp inspection validate command [2-145](#)
  - ip arp inspection vlan command [2-147](#)
  - ip arp inspection vlan logging command [2-148](#)
  - IP DHCP snooping
    - See DHCP snooping
  - ip dhcp snooping binding command [2-151](#)
  - ip dhcp snooping command [2-150](#)
  - ip dhcp snooping database command [2-153](#)
  - ip dhcp snooping information option allow-untrusted command [2-157](#)
  - ip dhcp snooping information option command [2-155](#)
  - ip dhcp snooping information option format remote-id command [2-159](#)
  - ip dhcp snooping limit rate command [2-160](#)
  - ip dhcp snooping trust command [2-161](#)
  - ip dhcp snooping verify command [2-162](#)
  - ip dhcp snooping vlan command [2-163](#)
  - ip dhcp snooping vlan information option format-type circuit-id string command [2-164](#)
  - ip igmp filter command [2-166](#)
  - ip igmp max-groups command [2-168](#), [2-191](#), [2-193](#)
  - ip igmp profile command [2-170](#)
  - ip igmp snooping command [2-172](#)
  - ip igmp snooping last-member-query-interval command [2-174](#)
  - ip igmp snooping querier command [2-176](#)
  - ip igmp snooping report-suppression command [2-178](#)
  - ip igmp snooping tcn command [2-180](#)
  - ip igmp snooping tcn flood command [2-181](#)
  - ip igmp snooping vlan immediate-leave command [2-182](#)
  - ip igmp snooping vlan mrouter command [2-183](#)
  - ip igmp snooping vlan static command [2-185](#)
  - IP multicast addresses [2-268](#)
  - IP precedence, as match criteria for QoS groups [2-253](#)
  - ip source binding command [2-187](#)
  - IP source guard
    - disabling [2-195](#)
    - displaying
      - binding entries [2-455](#)
      - configuration [2-456](#)
    - enabling [2-195](#)
    - static IP source bindings [2-187](#)
  - IP source guard, displaying dynamic binding entries [2-439](#)
  - ip ssh command [2-189](#)
  - IPv6 access list, deny conditions [2-70](#)
  - ipv6 access-list command [2-196](#)
  - ipv6 address dhcp command [2-198](#)
  - ipv6 dhcp client request vendor command [2-199](#)
  - ipv6 dhcp ping packets command [2-200](#)
  - ipv6 dhcp pool command [2-201](#)
  - ipv6 dhcp server command [2-203](#)
  - IPv6 SDM template [2-340](#)
  - ipv6 traffic-filter command [2-205](#)
  - ip verify source command [2-195](#)
- 
- ## J
- jumbo frames
    - See MTU
- 
- ## L
- l2protocol-tunnel command [2-207](#)
  - l2protocol-tunnel cos command [2-210](#)
  - LACP
    - See EtherChannel
  - lACP port-priority command [2-211](#)
  - lACP system-priority command [2-213](#)
  - Layer 2 mode, enabling [2-629](#)
  - Layer 2 protocol ports, displaying [2-467](#)
  - Layer 2 protocol-tunnel
    - error detection for [2-102](#)
    - error recovery timer [2-104](#)



Layer 2 protocol tunnel counters [2-45](#)  
 Layer 2 protocol tunneling error recovery [2-208](#)  
 Layer 2 traceroute  
   IP addresses [2-671](#)  
   MAC addresses [2-668](#)  
 Layer 3 mode, enabling [2-629](#)  
 line configuration mode [1-2, 1-4](#)  
 Link Aggregation Control Protocol  
   See EtherChannel  
 link flap  
   error detection for [2-102](#)  
   error recovery timer [2-104](#)  
 link state group command [2-215](#)  
 link state track command [2-217](#)  
 load-distribution methods for EtherChannel [2-306](#)  
 location (global configuration) command [2-218](#)  
 location (interface configuration) command [2-220](#)  
 logging event command [2-222](#)  
 logging file command [2-223](#)  
 logical interface [2-127](#)  
 loopback error  
   detection for [2-102](#)  
   recovery timer [2-104](#)  
 loop guard, for spanning tree [2-588, 2-592](#)

---

## M

mac access-group command [2-225](#)  
 MAC access-groups, displaying [2-482](#)  
 MAC access list configuration mode [2-227](#)  
 mac access-list extended command [2-227](#)  
 MAC access lists [2-75](#)

MAC addresses  
   disabling MAC address learning per VLAN [2-230](#)  
   displaying  
     aging time [2-488](#)  
     all [2-486](#)  
     dynamic [2-492](#)  
     MAC address-table move updates [2-497](#)  
     notification settings [2-496, 2-499](#)  
     number of addresses in a VLAN [2-490](#)  
     per interface [2-494](#)  
     per VLAN [2-503](#)  
     static [2-501](#)  
     static and dynamic entries [2-484](#)  
   dynamic  
     aging time [2-229](#)  
     deleting [2-48](#)  
     displaying [2-492](#)  
   enabling MAC address notification [2-234](#)  
   enabling MAC address-table move update [2-232](#)  
   matching [2-247](#)  
   static  
     adding and removing [2-236](#)  
     displaying [2-501](#)  
     dropping on an interface [2-237](#)  
   tables [2-486](#)  
 MAC address notification, debugging [B-14](#)  
 mac address-table aging-time [2-225, 2-247](#)  
 mac address-table aging-time command [2-229](#)  
 mac address-table learning command [2-230](#)  
 mac address-table move update command [2-232](#)  
 mac address-table notification command [2-234](#)  
 mac address-table static command [2-236](#)  
 mac address-table static drop command [2-237](#)  
 macro description command [2-241](#)  
 macro global command [2-242](#)  
 macro global description command [2-244](#)  
 macro name command [2-245](#)

## macros

- adding a description [2-241](#)
- adding a global description [2-244](#)
- applying [2-242](#)
- creating [2-245](#)
- displaying [2-515](#)
- interface range [2-65, 2-129](#)
- specifying parameter values [2-242](#)
- tracing [2-242](#)

maintenance end points [2-678](#)

mapping tables, QoS [2-664](#)

## maps

## class

- creating [2-37](#)

## VLAN

- creating [2-687](#)
- defining [2-247](#)
- displaying [2-557](#)

match access-group command [2-249](#)

match cos command [2-250](#)

match ip dscp command [2-251](#)

match ip precedence command [2-253](#)

match qos-group command [2-255](#)

match vlan command [2-257](#)

maximum transmission unit

See MTU

mdix auto command [2-260](#)

ME 3400EG-2CS switch policers [C-26](#)

ME 3400E-24TS switch policers [C-26, C-27](#)

ME 3400EG-12CS switch policers [C-26](#)

media-type command [2-262](#)

memory (boot loader) command [A-14](#)

mgmt\_clr (boot loader) command [A-15](#)

mgmt\_init (boot loader) command [A-16, A-17](#)

mkdir (boot loader) command [A-18](#)

mode, MVR [2-268](#)

modes, commands [1-1](#)

monitor session command [2-264](#)

more (boot loader) command [A-19](#)

## MSTP

displaying [2-537](#)

interoperability [2-56](#)

link type [2-590](#)

## MST region

aborting changes [2-596](#)

applying changes [2-596](#)

configuration name [2-596](#)

configuration revision number [2-597](#)

current or pending display [2-597](#)

displaying [2-537](#)

MST configuration mode [2-596](#)

VLANs-to-instance mapping [2-596](#)

path cost [2-598](#)

protocol mode [2-594](#)

restart protocol migration process [2-56](#)

## root port

loop guard [2-588](#)

preventing from becoming designated [2-588](#)

restricting which can be root [2-588](#)

root guard [2-588](#)

## root switch

affects of extended system ID [2-586](#)

hello-time [2-601, 2-612](#)

interval between BPDU messages [2-603](#)

interval between hello BPDU messages [2-601, 2-612](#)

max-age [2-603](#)

maximum hop count before discarding BPDU [2-605](#)

port priority for selection of [2-607](#)

primary or secondary [2-612](#)

switch priority [2-610](#)

## MSTP (continued)

## state changes

- blocking to forwarding state [2-619](#)
- enabling BPDU filtering [2-578, 2-616](#)
- enabling BPDU guard [2-580, 2-616](#)
- enabling Port Fast [2-616, 2-619](#)
- forward-delay time [2-600](#)
- length of listening and learning states [2-600](#)
- rapid transition to forwarding [2-590](#)
- shutting down Port Fast-enabled ports [2-616](#)

state information display [2-536](#)

## MTU

- configuring size [2-662](#)
- displaying global setting [2-544](#)

multicast group address, MVR [2-271](#)multicast groups, MVR [2-269](#)multicast router learning method [2-183](#)multicast router ports, configuring [2-183](#)multicast storm control [2-626](#)multicast VLAN, MVR [2-268](#)

## multicast VLAN registration

See MVR

multiple hosts on authorized port [2-85](#)

## Multiple Spanning Tree Protocol

See MSTP

multiplexing, UNI [2-118](#)

## MVR

- and address aliasing [2-269](#)
- configuring [2-268](#)
- configuring interfaces [2-271](#)
- debug messages, display [B-18](#)
- displaying [2-507](#)
- displaying interface information [2-509](#)
- members, displaying [2-511](#)

mvr (global configuration) command [2-268](#)mvr (interface configuration) command [2-271](#)mvr vlan group command [2-272](#)**N**native VLANs [2-656](#)native VLAN tagging [2-689](#)network node interface [2-308](#)nonegotiate, speed [2-624, 2-625](#)

## non-IP protocols

denying [2-75](#)forwarding [2-286](#)non-IP traffic access lists [2-227](#)

## non-IP traffic forwarding

denying [2-75](#)permitting [2-286](#)normal-range VLANs [2-684](#)no vlan command [2-684](#)**O**OAM PDUs [2-116](#)OAM protocol [2-274](#)oam protocol cfm svlan command [2-274](#)on-board failure logging, displaying [2-478](#)on-board failure logging, enabling [2-125](#)

## online diagnostics

enabling

scheduling [2-80](#)

global configuration mode

clearing test-based testing schedule [2-80](#)setting test-based testing [2-80](#)setting up test-based testing [2-80](#)removing scheduling [2-80](#)

scheduled switchover

disabling [2-80](#)enabling [2-80](#)setting test interval [2-80](#)starting testing [2-82](#)online diagnostic tests, displaying results [2-388](#)online diagnostic tests, starting [2-82](#)

operation, administration, and maintenance protocol

See OAM

output policy maps

and QoS group classification [2-255](#)

and traffic shaping [2-362](#)

commands not supported in [2-304](#)

configuration guidelines [2-304](#)

priority in [2-313](#)

queue limit in [2-320](#)

## P

PAGP

See EtherChannel

pagp learn-method command [2-275](#)

pagp port-priority command [2-277](#)

parent policy maps [2-349](#)

password-recovery mechanism, enabling and disabling [2-345](#)

permit (ARP access-list configuration) command [2-279](#)

permit (IPv6) command [2-281](#)

permit command [2-286](#)

per-VLAN spanning-tree plus

See STP

physical-port learner [2-275](#)

PID, displaying [2-433](#)

PIM-DVMRP, as multicast router learning method [2-183](#)

police

multiple conform actions for a class [2-59](#)

multiple exceed actions for a class [2-121](#)

multiple violate actions for a class [2-682](#)

with priority [2-289](#)

police aggregate command [2-299](#)

police command [2-289](#)

policer aggregate command [2-295](#)

policer configuration

default for NNIs [C-29](#)

default for UNIs [C-27](#)

policer cpu uni command [2-301](#)

policers

aggregate [2-295, 2-299](#)

for CPU protection [2-301](#)

individual [2-289](#)

policy-map class, configuring multiple actions [2-59, 2-121, 2-682](#)

policy-map class configuration mode [2-35](#)

policy-map class police configuration mode [2-59, 2-293](#)

policy-map command [2-303](#)

policy-map configuration mode [2-303](#)

policy maps

and CoS classification [2-250](#)

and DSCP classification [2-251](#)

and IP precedence classification [2-253](#)

and policing [2-292](#)

applying [2-347](#)

applying to an interface [2-304, 2-347, 2-359](#)

child [2-349](#)

creating [2-303](#)

displaying [2-521](#)

hierarchical [2-349](#)

parent [2-349](#)

policers

for a single class [2-289](#)

for multiple classes [2-295, 2-299, 2-301, 2-349](#)

setting priority [2-312](#)

setting QoS group identifier [2-357](#)

traffic classification, defining [2-35](#)

traffic marking

setting CoS values [2-351](#)

setting DSCP values [2-353](#)

setting IP precedence values [2-355](#)

Port Aggregation Protocol

See EtherChannel

port-based authentication

AAA method list [2-3](#)

configuring violation modes [2-99](#)

debug messages, display [B-3](#)

enabling 802.1x

- port-based authentication (continued)
    - globally [2-94](#)
    - per interface [2-90](#)
    - host modes [2-85](#)
    - IEEE 802.1x AAA accounting methods [2-1](#)
    - initialize an interface [2-87, 2-96](#)
    - manual control of authorization state [2-90](#)
    - multiple hosts on authorized port [2-85](#)
    - periodic re-authentication
      - enabling [2-93](#)
      - time between attempts [2-97](#)
    - quiet period between failed authentication exchanges [2-97](#)
    - re-authenticating 802.1x-enabled ports [2-92](#)
    - resetting configurable 802.1x parameters [2-84](#)
    - switch-to-authentication server retransmission time [2-97](#)
    - switch-to-client frame-retransmission number [2-88 to 2-89](#)
    - switch-to-client retransmission time [2-97](#)
    - test for IEEE 802.1x readiness [2-95](#)
  - port-channel load-balance command [2-306](#)
  - Port Fast, for spanning tree [2-619](#)
  - port ranges, defining [2-47, 2-61, 2-63, 2-65](#)
  - ports, debugging [B-62](#)
  - ports, protected [2-654](#)
  - port security
    - aging [2-650](#)
    - debug messages, display [B-64](#)
    - enabling [2-646](#)
    - violation error recovery [2-104](#)
  - port shaping [2-363](#)
  - port-type command [2-308](#)
  - port types, MVR [2-271](#)
  - power information, displaying [2-396](#)
  - power-supply alarm indications, configuring [2-310](#)
  - power-supply dual command [2-310](#)
  - power-supply status, displaying [2-396](#)
  - precedence
    - for QoS traffic marking [2-355](#)
    - setting in policy maps [2-355](#)
  - priority command [2-312](#)
  - priority queuing, QoS [2-312](#)
  - priority with police, QoS [2-312](#)
  - private-vlan command [2-315](#)
  - private-vlan mapping command [2-318](#)
  - private VLANs
    - association [2-652](#)
    - configuring [2-315](#)
    - configuring ports [2-643](#)
    - displaying [2-552](#)
    - host ports [2-643](#)
    - mapping
      - configuring [2-652](#)
      - displaying [2-418](#)
    - promiscuous ports [2-643](#)
  - privileged EXEC mode [1-2, 1-3](#)
  - product identification information, displaying [2-433](#)
  - promiscuous ports, private VLANs [2-643](#)
  - PVST+
    - See STP
- 
- ## Q
- QoS
    - aggregate policers
      - applying [2-299](#)
      - creating [2-295](#)
      - displaying [2-517](#)
    - class maps
      - creating [2-37](#)
      - defining the match criteria [2-250](#)
      - displaying [2-373](#)
    - conform actions, configuring [2-60](#)
    - displaying statistics for [2-521, C-35](#)
    - exceed actions, configuring [2-122](#)

## QoS (continued)

## policy maps

applying an aggregate policer [2-295, 2-299, 2-301, 2-349](#)

applying to an interface [2-347, 2-359](#)

creating [2-303](#)

defining policers [2-289](#)

displaying policy maps [2-521](#)

setting CoS values [2-351](#)

setting DSCP values [2-353](#)

setting IP precedence values [2-355](#)

setting QoS group identifier [2-357](#)

traffic classifications [2-35](#)

## table maps

configuring [2-664](#)

displaying [2-545](#)

violate actions, configuring [2-683](#)

## QoS groups

as match criteria [2-255](#)

for QoS traffic classification [2-357](#)

setting in policy maps [2-357](#)

## QoS match criteria

ACLs [2-249](#)

CoS value [2-250](#)

DSCP value [2-251, 2-257](#)

precedence value [2-253](#)

QoS group number [2-255](#)

## quality of service

See QoS

querytime, MVR [2-268](#)

queue-limit command [2-320](#)

**R**

## rapid per-VLAN spanning-tree plus

See STP

## rapid PVST+

See STP

re-authenticating 802.1x-enabled ports [2-92](#)

## re-authentication

periodic [2-93](#)

time between attempts [2-97](#)

receiver ports, MVR [2-271](#)

receiving flow-control packets [2-123](#)

## recovery mechanism

causes [2-104](#)

display [2-371, 2-398, 2-402](#)

timer interval [2-105](#)

remote-span command [2-323](#)

## Remote Switched Port Analyzer

See RSPAN

rename (boot loader) command [A-20](#)

renew ip dhcp snooping database command [2-325](#)

rep admin vlan command [2-326](#)

rep block port command [2-327](#)

rep lsl-age-timer command [2-330](#)

rep preempt delay command [2-331](#)

rep preempt segment command [2-333](#)

rep segment command [2-334](#)

rep stcn command [2-337](#)

reset (boot loader) command [A-21](#)

resource templates, displaying [2-534](#)

rmdir (boot loader) command [A-22](#)

rmon collection stats command [2-339](#)

root guard, for spanning tree [2-588](#)

## routed ports

IP addresses on [2-137](#)

number supported [2-137](#)

## RSPAN

configuring [2-264](#)

displaying [2-505](#)

filter RSPAN traffic [2-264](#)

remote-span command [2-323](#)

## sessions

add interfaces to [2-264](#)

displaying [2-505](#)

start new [2-264](#)

## S

- scheduled switchover
  - disabling [2-80](#)
  - enabling [2-80](#)
- scheduling diagnostic tests [2-80](#)
- sdm prefer command [2-340](#)
- SDM templates
  - allowed resources [2-341](#)
  - displaying [2-534](#)
  - dual IPv4 and IPv6 [2-340](#)
- secure ports, limitations [2-648](#)
- sending flow-control packets [2-123](#)
- service instance command [2-343](#)
- service instances, displaying [2-410](#)
- service password-recovery command [2-345](#)
- service policy (policy-map class configuration) command [2-349](#)
- service-policy interface configuration command [2-347](#)
- service-policy policy-map class configuration command [2-349](#)
- set (boot loader) command [A-23](#)
- set cos command [2-351](#)
- set dscp command [2-353](#)
- set precedence command [2-355](#)
- set qos-group command [2-357](#)
- setup command [2-359](#)
- SFPs, displaying information about [2-433](#)
- shape average command [2-362](#)
- show access-lists command [2-364](#)
- show aggregate-policer command [2-545](#)
- show archive status command [2-367](#)
- show arp access-list command [2-368](#)
- show boot command [2-369](#)
- show class-map command [2-373](#)
- show controllers cpu-interface command [2-374](#)
- show controllers ethernet-controller command [2-376](#)
- show controllers team command [2-383](#)
- show controllers utilization command [2-385](#)
- show controller utilization command [2-385](#)
- show cpu traffic qos [2-387](#)
- show diagnostic command [2-388](#)
- show dot1q-tunnel command [2-392](#)
- show dot1x command [2-393](#)
- show env command [2-396](#)
- show errdisable detect command [2-398](#)
- show errdisable flap-values command [2-400](#)
- show errdisable recovery command [2-402](#)
- show etherchannel command [2-404](#)
- show ethernet loopback command [2-407](#)
- show ethernet service evc command [2-409](#)
- show ethernet service instance command [2-410](#)
- show ethernet service interface command [2-412](#)
- show flowcontrol command [2-414](#)
- show idprom command [2-416](#)
- show interface rep command [2-428](#)
- show interfaces command [2-418](#)
- show interfaces counters command [2-426](#)
- show interfaces rep command [2-428](#)
- show interface transceivers command [2-430](#)
- show inventory command [2-433](#)
- show ip arp inspection command [2-434](#)
- show ipc command [2-458](#)
- show ip dhcp snooping binding command [2-439](#)
- show ip dhcp snooping command [2-438](#)
- show ip dhcp snooping database command [2-441, 2-443](#)
- show ip igmp profile command [2-446](#)
- show ip igmp snooping command [2-447](#)
- show ip igmp snooping command querier detail [2-453](#)
- show ip igmp snooping groups command [2-449](#)
- show ip igmp snooping mrouter command [2-451](#)
- show ip igmp snooping querier command [2-453](#)
- show ip igmp snooping querier detail command [2-453](#)
- show ip source binding command [2-455](#)
- show ipv6 access-list command [2-462](#)
- show ipv6 dhcp conflict command [2-464](#)
- show ipv6 route updated [2-465](#)
- show ipv6 route updated command [2-465](#)

- show ip verify source command [2-456](#)
- show l2protocol-tunnel command [2-467](#)
- show lacp command [2-469](#)
- show link state group command [2-473](#)
- show location [2-475](#)
- show location command [2-475](#)
- show logging onboard command [2-478](#)
- show mac access-group command [2-482](#)
- show mac address-table address command [2-486](#)
- show mac address-table aging time command [2-488](#)
- show mac address-table command [2-484](#)
- show mac address-table count command [2-490](#)
- show mac address-table dynamic command [2-492](#)
- show mac address-table interface command [2-494](#)
- show mac address-table learning command [2-496](#)
- show mac address-table move update command [2-497](#)
- show mac address-table notification command [2-49, 2-499, B-16](#)
- show mac address-table static command [2-501](#)
- show mac address-table vlan command [2-503](#)
- show monitor command [2-505](#)
- show mvr command [2-507](#)
- show mvr interface command [2-509](#)
- show mvr members command [2-511](#)
- show pagp command [2-513](#)
- show parser macro command [2-515](#)
- show platform acl command [C-2](#)
- show platform backup interface command [C-3](#)
- show platform cfm command [C-4](#)
- show platform configuration command [C-5](#)
- show platform dl command [C-6](#)
- show platform etherchannel command [C-7](#)
- show platform forward command [C-8](#)
- show platform frontend-controller command [C-10](#)
- show platform igmp snooping command [C-11](#)
- show platform ipc trace command [C-16](#)
- show platform ip multicast command [C-13](#)
- show platform ip unicast command [C-14](#)
- show platform ipv6 unicast command [C-17](#)
- show platform l2pt dm command [C-19](#)
- show platform layer4op command [C-20, C-42](#)
- show platform mac-address-table command [C-21](#)
- show platform messaging command [C-22](#)
- show platform monitor command [C-23](#)
- show platform mvr table command [C-24](#)
- show platform pm command [C-25](#)
- show platform policer cpu command [C-26](#)
- show platform port-asic command [C-30](#)
- show platform port-security command [C-34](#)
- show platform qos command [C-35](#)
- show platform resource-manager command [C-38](#)
- show platform snmp counters command [C-40](#)
- show platform spanning-tree synchronization command [C-41](#)
- show platform stp-instance command [C-43](#)
- show platform tcam command [C-44](#)
- show platform vlan command [C-47](#)
- show platform vlan mapping command [C-48](#)
- show policer aggregate command [2-517](#)
- show policer cpu uni-eni command [2-518](#)
- show policy-map command [2-521](#)
- show policy-map interface output fields [2-524](#)
- show port security command [2-526](#)
- show port-type command [2-529](#)
- show rep topology command [2-531](#)
- show sdm prefer command [2-534](#)
- show spanning-tree command [2-536](#)
- show storm-control command [2-542](#)
- show system mtu command [2-544](#)
- show udd command [2-547](#)
- show version command [2-550](#)
- show vlan access-map command [2-557](#)
- show vlan command [2-552](#)
- show vlan command, fields [2-554](#)
- show vlan filter command [2-558](#)
- show vlan mapping command [2-559](#)
- show vmmps command [2-561](#)
- shutdown command [2-563](#)



- shutdown threshold, Layer 2 protocol tunneling [2-207](#)
- shutdown vlan command [2-564](#)
- SNMP host, specifying [2-570](#)
- SNMP informs, enabling the sending of [2-566](#)
- snmp mib rep trap-rate command [2-565](#)
- snmp-server enable traps command [2-566](#)
- snmp-server host command [2-570](#)
- snmp trap mac-notification command [2-574](#)
- SNMP traps
  - enabling MAC address notification trap [2-574](#)
  - enabling the MAC address notification feature [2-234](#)
  - enabling the sending of [2-566](#)
- software images
  - deleting [2-67](#)
  - downloading [2-9](#)
  - upgrading [2-9](#)
  - uploading [2-15](#)
- software version, displaying [2-550](#)
- source ports, MVR [2-271](#)
- SPAN
  - configuring [2-264](#)
  - debug messages, display [B-17](#)
  - displaying [2-505](#)
  - filter SPAN traffic [2-264](#)
  - sessions
    - add interfaces to [2-264](#)
    - displaying [2-505](#)
    - start new [2-264](#)
- spanning-tree bpdudfilter command [2-576, 2-578](#)
- spanning-tree bpduguard command [2-580](#)
- spanning-tree cost command [2-582](#)
- spanning-tree etherchannel command [2-584](#)
- spanning-tree extend system-id command [2-586](#)
- spanning-tree guard command [2-588](#)
- spanning-tree link-type command [2-590](#)
- spanning-tree loopguard default command [2-592](#)
- spanning-tree mode command [2-594](#)
- spanning-tree mst configuration command [2-596](#)
- spanning-tree mst cost command [2-598](#)
- spanning-tree mst forward-time command [2-600](#)
- spanning-tree mst hello-time command [2-601](#)
- spanning-tree mst max-age command [2-603](#)
- spanning-tree mst max-hops command [2-605](#)
- spanning-tree mst port-priority command [2-607](#)
- spanning-tree mst pre-standard command [2-609](#)
- spanning-tree mst priority command [2-610](#)
- spanning-tree mst root command [2-612](#)
- spanning-tree portfast (global configuration) command [2-616](#)
- spanning-tree portfast (interface configuration) command [2-619](#)
- spanning-tree port-priority command [2-614](#)
- Spanning Tree Protocol
  - See STP
- spanning-tree vlan command [2-621](#)
- speed command [2-624](#)
- SSH, configuring version [2-189](#)
- static-access ports, configuring [2-631](#)
- statistics, Ethernet group [2-339](#)
- sticky learning, enabling [2-646](#)
- storm-control command [2-626](#)
- STP
  - counters, clearing [2-55](#)
  - debug messages, display
    - MSTP [B-70](#)
    - optimized BPDUs handling [B-69](#)
    - spanning-tree activity [B-66](#)
    - switch shim [B-72](#)
    - transmitted and received BPDUs [B-68](#)
  - enabling on ENIs [2-576](#)
  - enabling protocol tunneling for [2-207](#)
  - EtherChannel misconfiguration [2-584](#)
  - extended system ID [2-586](#)
  - path cost [2-582](#)
  - protocol modes [2-594](#)

## STP (continued)

## root port

- loop guard [2-588](#)
- preventing from becoming designated [2-588](#)
- restricting which can be root [2-588](#)
- root guard [2-588](#)

## root switch

- affects of extended system ID [2-586, 2-622](#)
- hello-time [2-621](#)
- interval between BDPDU messages [2-621](#)
- interval between hello BPDU messages [2-621](#)
- max-age [2-621](#)
- port priority for selection of [2-614](#)
- primary or secondary [2-621](#)
- switch priority [2-621](#)

## state changes

- blocking to forwarding state [2-619](#)
- enabling BPDU filtering [2-578, 2-616](#)
- enabling BPDU guard [2-580, 2-616](#)
- enabling Port Fast [2-616, 2-619](#)
- enabling timer to recover from error state [2-104](#)
- forward-delay time [2-621](#)
- length of listening and learning states [2-621](#)
- shutting down Port Fast-enabled ports [2-616](#)

state information display [2-536](#)VLAN options [2-610, 2-621](#)SVIs, creating [2-131](#)

## Switched Port Analyzer

See SPAN

## switching characteristics

- modifying [2-629](#)
- returning to interfaces [2-629](#)

switchport access command [2-631](#)switchport backup interface command [2-633](#)switchport block command [2-637](#)switchport command [2-629](#)switchport host command [2-639](#)switchport mode command [2-640](#)switchport mode private-vlan command [2-643](#)switchport port-security aging command [2-650](#)switchport port-security command [2-646](#)switchport private-vlan command [2-652](#)switchport protected command [2-654](#)switchports, displaying [2-418](#)switchport trunk command [2-656](#)switchport vlan mapping command [2-658](#)system env temperature threshold yellow command [2-661](#)system message logging, save message to flash [2-223](#)system mtu command [2-662](#)system resource templates [2-340](#)

---

**T**table-map command [2-664](#)table-map configuration mode [2-664](#)

## table maps

- configuring [2-664](#)
- displaying [2-545](#)
- QoS [2-664](#)

tar files, creating, listing, and extracting [2-12](#)TDR, running [2-666](#)temperature information, displaying [2-396](#)temperature status, displaying [2-396](#)templates, system resources [2-340](#)test cable-diagnostics tdr command [2-666](#)traceroute mac command [2-668](#)traceroute mac ip command [2-671](#)traffic shaping, QoS [2-362](#)trunking, VLAN mode [2-640](#)trunk mode [2-640](#)trunk ports [2-640](#)tunnel ports, Layer 2 protocol, displaying [2-467](#)type (boot loader) command [A-26](#)

---

**U**

## UDLD

- aggressive mode [2-673, 2-675](#)
- debug messages, display [B-78](#)
- enable globally [2-673](#)
- enable per interface [2-675](#)
- error recovery timer [2-104](#)
- message timer [2-673](#)
- normal mode [2-673, 2-675](#)
- reset a shutdown interface [2-677](#)
- status [2-547](#)

udld command [2-673](#)

udld port command [2-675](#)

udld reset command [2-677](#)

## UNI

- bundling and multiplexing [2-118](#)
- Ethernet [2-118](#)

unicast storm control [2-626](#)

uni count command [2-678](#)

## UniDirectional Link Detection

See UDLD

UNI ID, Ethernet [2-120](#)

uni-vlan command [2-680](#)

unknown multicast traffic, preventing [2-637](#)

unknown unicast traffic, preventing [2-637](#)

unset (boot loader) command [A-27](#)

## upgrading

- software images [2-9](#)
- monitoring status of [2-367](#)

user EXEC mode [1-2](#)

user network interface [2-308](#)

---

**V**

version (boot loader) command [A-29](#)

violate-action command [2-682](#)

vlan access-map command [2-687](#)

VLAN access map configuration mode [2-687](#)

## VLAN access maps

actions [2-5](#)

displaying [2-557](#)

vlan command [2-684](#)

## VLAN configuration mode

commands [2-684](#)

description [1-4](#)

entering [2-684](#)

summary [1-2](#)

vlan dot1q tag native command [2-689](#)

vlan filter command [2-691](#)

VLAN filters, displaying [2-558](#)

VLAN ID range [2-684](#)

## VLAN ID translation

See VLAN mapping

## VLAN mapping

configuring [2-658](#)

described [2-659](#)

displaying [2-559](#)

## VLAN maps

applying [2-691](#)

creating [2-687](#)

defining [2-247](#)

displaying [2-557](#)

## VLAN Query Protocol

See VQP

## VLANs

adding [2-684](#)

configuring [2-684](#)

debug messages, display

activation of [B-76](#)

VLAN IOS file system error tests [B-75](#)

VLAN manager activity [B-74](#)

displaying configurations [2-552](#)

extended-range [2-684](#)

## MAC addresses

displaying [2-503](#)

number of [2-490](#)

normal-range [2-684](#)

## VLANs (continued)

private [2-643](#)

    configuring [2-315](#)

    displaying [2-552](#)

    See also private VLANs

restarting [2-564](#)

saving the configuration [2-684](#)

shutting down [2-564](#)

suspending [2-564](#)

## VMPS

configuring servers [2-696](#)

displaying [2-561](#)

error recovery timer [2-105](#)

reconfirming dynamic VLAN assignments [2-693](#)

vmmps reconfirm (global configuration) command [2-694](#)

vmmps reconfirm (privileged EXEC) command [2-693](#)

vmmps retry command [2-695](#)

vmmps server command [2-696](#)

## VQP

and dynamic-access ports [2-632](#)

clearing client statistics [2-58](#)

displaying information [2-561](#)

per-server retry count [2-695](#)

reconfirmation interval [2-694](#)

reconfirming dynamic VLAN assignments [2-693](#)

VTP, enabling tunneling for [2-207](#)

---

**W**

Weighted Tail Drop

    See WTD

WTD, queue-limit command [2-320](#)