



## INDEX

---

### A

aaa accounting dot1x command [2-1](#)  
aaa authentication dot1x command [2-3](#)  
AAA methods [2-3](#)  
access control entries  
    See ACEs  
access control lists  
    See ACLs  
access groups  
    IP [2-151](#)  
    MAC, displaying [2-536](#)  
    matching for QoS classification [2-287](#)  
access list, IPv6 [2-220](#)  
access mode [2-690](#)  
access ports [2-690](#)  
ACEs [2-91](#), [2-332](#)  
ACLs  
    as match criteria for QoS classes [2-287](#)  
    deny [2-89](#)  
    displaying [2-412](#)  
    for non-IP protocols [2-265](#)  
    IP [2-151](#)  
    on Layer 2 interfaces [2-151](#)  
    permit [2-330](#)  
action command [2-5](#)  
address aliasing [2-310](#)  
aggregate policers  
    applying [2-343](#)  
    creating [2-338](#)  
    displaying [2-568](#)  
    QoS [2-340](#)  
aggregate-port learner [2-319](#)

alarm-contact command [2-7](#)  
alarm-contact status, displaying [2-445](#)  
allowed VLANs [2-706](#)  
archive download-sw command [2-9](#)  
archive tar command [2-12](#)  
archive upload-sw command [2-15](#)  
arp (boot loader) command [A-2](#)  
arp access-list command [2-17](#)  
attaching policy maps to interfaces [2-393](#)  
authorization state of controlled port [2-105](#)  
autonegotiation of duplex mode [2-117](#)

---

### B

backup interfaces  
    configuring [2-683](#)  
    displaying [2-467](#)  
bandwidth, configuring for QoS [2-19](#)  
bandwidth command [2-19](#)  
boot (boot loader) command [A-3](#)  
boot config-file command [2-23](#)  
boot enable-break command [2-24](#)  
boot helper command [2-25](#)  
boot helper-config file command [2-26](#)  
booting  
    Cisco IOS image [2-29](#)  
    displaying environment variables [2-417](#)  
    interrupting [2-24](#)  
    manually [2-27](#)

## boot loader

- accessing [A-1](#)

- booting

- Cisco IOS image [A-3](#)

- helper image [2-25](#)

- directories

- creating [A-18](#)

- displaying a list of [A-8](#)

- removing [A-22](#)

- displaying

- available commands [A-13](#)

- memory heap utilization [A-14](#)

- version [A-29](#)

- environment variables

- described [A-23](#)

- displaying settings [A-23](#)

- location of [A-24](#)

- setting [A-23](#)

- unsetting [A-27](#)

- files

- copying [A-6](#)

- deleting [A-7](#)

- displaying a list of [A-8](#)

- displaying the contents of [A-5, A-19, A-26](#)

- renaming [A-20](#)

- file system

- formatting [A-11](#)

- initializing flash [A-10](#)

- running a consistency check [A-12](#)

- prompt [A-1](#)

- resetting the system [A-21](#)

- boot manual command [2-27](#)

- boot private-config-file command [2-28](#)

- boot system command [2-29](#)

- BPDU filtering, for spanning tree [2-628, 2-666](#)

- BPDU guard, for spanning tree [2-630, 2-666](#)

- broadcast storm control [2-676](#)

- bundling characteristics, UNI [2-127](#)

- burst bytes, in QoS policers [2-334, 2-339](#)

---

**C**

- cat (boot loader) command [A-5](#)

- CBWFQ, configuring [2-19](#)

- CDP, enabling protocol tunneling for [2-245](#)

- CFM [2-318](#)

- CFM as OAM protocol [2-318](#)

- channel-group command [2-30](#)

- channel-protocol command [2-34](#)

- child policy maps [2-395](#)

- class-based traffic shaping [2-410](#)

- class-based weighted fair queuing

- See CBWFQ

- class command [2-36](#)

- class-map command [2-38](#)

- class-map configuration mode [2-38](#)

- class maps

- creating [2-38](#)

- defining the match criteria [2-288, 2-290](#)

- displaying [2-421](#)

- matching in [2-38](#)

- class of service

- See CoS

- clear ip arp inspection log command [2-40](#)

- clear ip arp inspection statistics command [2-41](#)

- clear ipc command [2-44](#)

- clear ipv6 dhcp conflict command [2-45](#)

- clear l2protocol-tunnel counters command [2-46](#)

- clear lacp command [2-47](#)

- clear logging onboard command [2-48](#)

- clear mac address-table command [2-49, 2-50](#)

- clear pagp command [2-51, 2-55](#)

- clear policer cpu uni-eni counters command [2-52](#)

- clear port-security command [2-53](#)

- clear spanning-tree counters command [2-56](#)

- clear spanning-tree detected-protocols command [2-57](#)

- clear vmps statistics command [2-59](#)

- command modes defined [1-1](#)

- committed information rate in QoS policers [2-334, 2-338](#)

- configuration files
    - password recovery disable considerations [A-1](#)
    - specifying the name [2-23, 2-28](#)
  - configuring multiple interfaces [2-147](#)
  - conform-action command [2-60](#)
  - control-plane policer [2-52](#)
  - control-plane policer information, displaying [2-569](#)
  - control-plane security [2-345](#)
  - control plane statistics, clearing [2-52](#)
  - copy (boot loader) command [A-6](#)
  - copy logging onboard module command [2-62](#)
  - CoS
    - as match criteria for QoS groups [2-288](#)
    - for QoS classification [2-397](#)
    - setting value in policy maps [2-397](#)
  - CoS value, assigning to Layer 2 protocol packets [2-248](#)
  - CPU ASIC statistics, displaying [2-422](#)
  - CPU protection policers, displaying [C-24](#)
  - cpu traffic qos cos command [2-64](#)
  - cpu traffic qos dscp command [2-68](#)
  - cpu traffic qos precedence command [2-73](#)
  - cpu traffic qos qos-group command [2-76](#)
- 
- D**
- DC power supply [2-354](#)
  - debug backup command [B-2](#)
  - debug dot1x command [B-3](#)
  - debug etherchannel command [B-4](#)
  - debug interface command [B-7](#)
  - debug ip dhcp snooping command [B-8](#)
  - debug ip igmp filter command [B-9](#)
  - debug ip igmp max-groups command [B-10](#)
  - debug ip igmp snooping command [B-11](#)
  - debug ip sla error twamp connection command [B-12](#)
  - debug ip sla error twamp control reflector command [B-14](#)
  - debug ip sla error twamp control server command [B-16](#)
  - debug ip sla error twamp session command [B-18](#)
  - debug ip sla trace twamp connection command [B-20](#)
  - debug ip sla trace twamp control reflector command [B-22](#)
  - debug ip sla trace twamp control server command [B-24](#)
  - debug ip sla trace twamp session command [B-26](#)
  - debug ip verify source packet command [B-28](#)
  - debug lacp command [B-29](#)
  - debug mac-notification command [B-30](#)
  - debug matm command [B-31](#)
  - debug matm move update command [B-32](#)
  - debug monitor command [B-33](#)
  - debug mvrdbg command [B-34](#)
  - debug nvram command [B-35](#)
  - debug pagp command [B-36](#)
  - debug platform acl command [B-37](#)
  - debug platform backup interface command [B-38](#)
  - debug platform cfm command [B-39](#)
  - debug platform cpu-queues command [B-40](#)
  - debug platform dot1ad command [B-42](#)
  - debug platform dot1x command [B-43](#)
  - debug platform etherchannel command [B-44](#)
  - debug platform forw-tcam command [B-45](#)
  - debug platform ip arp inspection command [B-46](#)
  - debug platform ipc command [B-55](#)
  - debug platform ip dhcp command [B-47](#)
  - debug platform ip igmp snooping command [B-48](#)
  - debug platform ip multicast command [B-50](#)
  - debug platform ip source-guard command [B-52](#)
  - debug platform led command [B-56](#)
  - debug platform matm command [B-57](#)
  - debug platform messaging application command [B-58](#)
  - debug platform phy command [B-59](#)
  - debug platform pm command [B-61](#)
  - debug platform policer cpu uni-eni command [B-63](#)
  - debug platform port-asic command [B-64](#)
  - debug platform port-security command [B-65](#)
  - debug platform qos-acl-tcam command [B-66](#)
  - debug platform qos-manager command [B-67](#)
  - debug platform remote-commands command [B-68](#)
  - debug platform rep command [B-69](#)
  - debug platform resource-manager command [B-70](#)

- debug platform snmp command [B-71](#)
- debug platform span command [B-72](#)
- debug platform supervisor-asic command [B-73](#)
- debug platform sw-bridge command [B-74](#)
- debug platform team command [B-75](#)
- debug platform uddl command [B-77](#)
- debug platform vlan command [B-78](#)
- debug pm command [B-79](#)
- debug port-security command [B-81](#)
- debug qos-manager command [B-83](#)
- debug rep command [B-82](#)
- debug spanning-tree bpdu command [B-86](#)
- debug spanning-tree bpdu-opt command [B-87](#)
- debug spanning-tree command [B-84](#)
- debug spanning-tree mstp command [B-88](#)
- debug spanning-tree switch command [B-90](#)
- debug sw-vlan command [B-92](#)
- debug sw-vlan ifs command [B-93](#)
- debug sw-vlan notification command [B-94](#)
- debug uddl command [B-96](#)
- debug vqpc command [B-98](#)
- default policer configuration
  - NNIs [C-26](#)
  - UNIs [C-25](#)
- define interface-range command [2-78](#)
- delete (boot loader) command [A-7](#)
- delete command [2-80](#)
- deny (ARP access-list configuration) command [2-81](#)
- deny (IPv6) command [2-83](#)
- deny command [2-89](#)
- detect mechanism, causes [2-118](#)
- DHCP snooping
  - accepting untrusted packets from edge switch [2-176](#)
  - enabling
    - on a VLAN [2-182](#)
    - option 82 [2-174, 2-176](#)
    - trust on an interface [2-180](#)
  - error recovery timer [2-120](#)
  - rate limiting [2-179](#)
- DHCP snooping binding database
  - binding file, configuring [2-172](#)
  - bindings
    - adding [2-170](#)
    - deleting [2-170](#)
    - displaying [2-488](#)
  - clearing database agent statistics [2-42](#)
  - database agent, configuring [2-172](#)
  - displaying
    - binding entries [2-488](#)
    - database agent status [2-490, 2-492](#)
    - renewing [2-369](#)
- diagnostic monitor command [2-92](#)
- diagnostic schedule test command [2-94](#)
- diagnostic start test command [2-96](#)
- differentiated service code point
  - See DSCP
- Digital Optical Monitoring
  - see DoM
- dir (boot loader) command [A-8](#)
- directories, deleting [2-80](#)
- DoM
  - displaying supported transceivers [2-479, 2-618, 2-619](#)
- domains, CFM [2-318](#)
- dot1x default command [2-98](#)
- dot1x host-mode command [2-99](#)
- dot1x initialize command [2-101](#)
- dot1x max-req command [2-102, 2-104](#)
- dot1x port-control command [2-105](#)
- dot1x re-authenticate command [2-107](#)
- dot1x reauthentication command [2-108](#)
- dot1x supplicant force-multicast command [2-109](#)
- dot1x system-auth-control command [2-110](#)
- dot1x test eapol-capable command [2-111](#)
- dot1x test timeout command [2-112](#)
- dot1x timeout command [2-113](#)
- dot1x violation-mode command [2-115](#)
- drop eligibility indicator [2-399](#)
- drop eligibility indicator bit [2-290](#)

- dropping packets, with ACL matches [2-5](#)
- drop threshold, Layer 2 protocol tunneling [2-245](#)
- DSCP
  - as match criteria for QoS groups [2-292, 2-298](#)
  - for QoS traffic marking [2-401](#)
  - setting in policy maps [2-401](#)
- dual IPv4 and IPv6 templates [2-325](#)
- dual-purpose uplink ports, selecting the type [2-303](#)
- duplex command [2-116](#)
- dynamic-access ports
  - configuring [2-681](#)
  - restrictions [2-682](#)
- dynamic ARP inspection
  - ARP ACLs
    - apply to a VLAN [2-156](#)
    - define [2-17](#)
    - deny packets [2-81](#)
    - display [2-416](#)
    - permit packets [2-323](#)
  - clear
    - log buffer [2-40](#)
    - statistics [2-41](#)
  - display
    - ARP ACLs [2-416](#)
    - configuration and operating state [2-483](#)
    - log buffer [2-483](#)
    - statistics [2-483](#)
    - trust state and rate limit [2-483](#)
  - enable per VLAN [2-165](#)
  - error detection for [2-118](#)
  - error recovery timer [2-120](#)
  - log buffer
    - clear [2-40](#)
    - configure [2-160](#)
    - display [2-483](#)
  - rate-limit incoming ARP packets [2-158](#)
  - statistics
    - clear [2-41](#)
    - display [2-483](#)

- trusted interface state [2-162](#)
- type of packet logged [2-166](#)
- validation checks [2-163](#)

Dynamic Host Configuration Protocol (DHCP)  
See DHCP snooping

---

## E

- EAP-request/identity frame
  - maximum number to send [2-104](#)
  - response time before retransmitting [2-113](#)
- E-LMI
  - enabling [2-125](#)
  - mapping [2-127](#)
- environment variables, displaying [2-417](#)
- errdisable detect cause command [2-118](#)
- errdisable recovery command [2-120](#)
- error conditions, displaying [2-449](#)
- error disable detection [2-118](#)
- error-disabled interfaces, displaying [2-467](#)
- EtherChannel
  - assigning Ethernet interface to channel group [2-30](#)
  - creating port-channel logical interface [2-145](#)
  - debug EtherChannel/PAgP, display [B-4](#)
  - debug platform-specific events, display [B-44](#)
  - displaying [2-453](#)
  - enabling Layer 2 protocol tunneling for
    - LACP [2-246](#)
    - PAgP [2-246](#)
    - UDLD [2-246](#)
  - interface information, displaying [2-467](#)
  - LACP
    - clearing channel-group information [2-47](#)
    - debug messages, display [B-29](#)
    - displaying [2-523](#)
    - modes [2-30](#)
    - port priority for hot-standby ports [2-249](#)
    - restricting a protocol [2-34](#)
    - system priority [2-251](#)

load-distribution methods [2-350](#)

PAgP

- aggregate-port learner [2-319](#)
- clearing channel-group information [2-51](#)
- debug messages, display [B-36](#)
- displaying [2-564](#)
- error detection for [2-118](#)
- error recovery timer [2-120](#)
- learn method [2-319](#)
- modes [2-30](#)
- physical-port learner [2-319](#)
- priority of interface for transmitted traffic [2-321](#)

Ethernet controller, internal register display [2-424](#)

ethernet dot1ad command [2-122](#)

ethernet evc command [2-124](#)

ethernet lmi ce-vlan map command [2-125, 2-127](#)

ethernet lmi command [2-125](#)

ethernet lmi global command [2-125](#)

Ethernet Local Management Interface

- See E-LMI

ethernet loopback interface configuration command [2-129](#)

ethernet loopback privileged EXEC command [2-132](#)

ethernet oam remote-failure command [2-134](#)

Ethernet service

- debugging [B-5](#)
- displaying [2-458](#)

Ethernet service instance [2-389](#)

Ethernet service interfaces [2-461](#)

Ethernet statistics, collecting [2-385](#)

Ethernet UNI configuration [2-136](#)

ethernet uni id command [2-138](#)

Ethernet virtual connections

- See EVCs

EVC configuration mode [2-124](#)

EVCs [2-124](#)

- and VLANs [2-136](#)
- service instances [2-389](#)
- UNI counts [2-729](#)

EVC service

- point-to-multipoint [2-729](#)
- point-to-point [2-729](#)

exceed-action command [2-139](#)

extended-range VLANs

- and allowed VLAN list [2-706](#)
- configuring [2-735](#)

extended system ID for STP [2-636](#)

external alarms, configuring [2-7](#)

---

## F

failure logging data

- clearing [2-48](#)
- copying [2-62](#)

fan information, displaying [2-445](#)

files, deleting [2-80](#)

flash\_init (boot loader) command [A-10](#)

Flex Links

- configuring [2-683](#)
- configuring preferred VLAN [2-685](#)
- displaying [2-467](#)

flowcontrol command [2-141](#)

format (boot loader) command [A-11](#)

forwarding packets, with ACL matches [2-5](#)

forwarding results, display [C-8](#)

frame forwarding information, displaying [C-8](#)

front-end controller counter and status information [C-10](#)

fsck (boot loader) command [A-12](#)

---

## G

global configuration mode [1-2, 1-3](#)

---

## H

hardware ACL statistics [2-412](#)

health-monitoring diagnostic testing [2-92](#)

help (boot loader) command [A-13](#)  
 host connection, port configuration [2-689](#)  
 host ports, private VLANs [2-693](#)  
 hw-module module logging onboard command [2-143](#)

## I

IEEE 802.1ag Connectivity Fault Management

See CFM

IEEE 802.1Q trunk ports and native VLANs [2-740](#)

IEEE 802.1Q tunnel ports

configuring [2-690](#)

displaying [2-441](#)

limitations [2-691](#)

IEEE 802.1x

and switchport modes [2-691](#)

violation error recovery [2-120](#)

See also port-based authentication

IGMP filters

applying [2-185](#)

debug messages, display [B-9](#)

IGMP groups, setting maximum [2-187](#)

IGMP maximum groups, debugging [B-10](#)

IGMP profiles

creating [2-189](#)

displaying [2-497](#)

IGMP snooping

adding ports as a static member of a group [2-204](#)

displaying [2-498, 2-502, 2-503](#)

enabling [2-191](#)

enabling the configurable-leave timer [2-193](#)

enabling the Immediate-Leave feature [2-201](#)

flooding query count [2-199](#)

interface topology change notification behavior [2-200](#)

multicast table [2-500](#)

querier [2-195](#)

query solicitation [2-199](#)

report suppression [2-197](#)

switch topology change notification behavior [2-199](#)

images

See software images

Immediate-Leave feature, MVR [2-312](#)

immediate-leave processing [2-201](#)

Immediate-Leave processing, IPv6 [2-241](#)

input policy maps

and ACL classification [2-287](#)

and aggregate policers [2-340](#)

commands not supported in [2-348](#)

configuration guidelines [2-348](#)

interface command [2-149](#)

interface configuration mode [1-2, 1-4](#)

interface port-channel command [2-145](#)

interface range command [2-147](#)

interface-range macros [2-78](#)

interfaces

assigning Ethernet interface to channel group [2-30](#)

configuring [2-116](#)

configuring multiple [2-147](#)

creating port-channel logical [2-145](#)

debug messages, display [B-7](#)

disabling [2-613](#)

displaying the MAC address table [2-546](#)

restarting [2-613](#)

interface speed, configuring [2-674](#)

internal registers, displaying [2-424, 2-431](#)

Internet Group Management Protocol

See IGMP

invalid GBIC

error detection for [2-118](#)

error recovery timer [2-120](#)

ip address command [2-154](#)

IP addresses, setting [2-154](#)

IP address matching [2-285](#)

ip arp inspection filter vlan command [2-156](#)

ip arp inspection limit command [2-158](#)

ip arp inspection log-buffer command [2-160](#)

ip arp inspection trust command [2-162](#)

ip arp inspection validate command [2-163](#)

- ip arp inspection vlan command [2-165](#)
- ip arp inspection vlan logging command [2-166](#)
- IP DHCP snooping
  - See DHCP snooping
- ip dhcp snooping binding command [2-170](#)
- ip dhcp snooping command [2-169](#)
- ip dhcp snooping database command [2-172](#)
- ip dhcp snooping information option allow-untrusted command [2-176](#)
- ip dhcp snooping information option command [2-174](#)
- ip dhcp snooping information option format remote-id command [2-178](#)
- ip dhcp snooping limit rate command [2-179](#)
- ip dhcp snooping trust command [2-180](#)
- ip dhcp snooping verify command [2-181](#)
- ip dhcp snooping vlan command [2-182](#)
- ip dhcp snooping vlan information option format-type circuit-id string command [2-183](#)
- ip igmp filter command [2-185](#)
- ip igmp max-groups command [2-187](#), [2-214](#), [2-216](#)
- ip igmp profile command [2-189](#)
- ip igmp snooping command [2-191](#)
- ip igmp snooping last-member-query-interval command [2-193](#)
- ip igmp snooping querier command [2-195](#)
- ip igmp snooping report-suppression command [2-197](#)
- ip igmp snooping tcn command [2-199](#)
- ip igmp snooping tcn flood command [2-200](#)
- ip igmp snooping vlan immediate-leave command [2-201](#)
- ip igmp snooping vlan mrouter command [2-202](#)
- ip igmp snooping vlan static command [2-204](#)
- IP multicast addresses [2-309](#)
- IP precedence, as match criteria for QoS groups [2-294](#)
- ip sla responder twamp command [2-206](#)
- ip sla server twamp command [2-208](#)
- ip source binding command [2-210](#)
- IP source guard
  - disabling [2-218](#)
  - displaying
    - binding entries [2-509](#)
    - configuration [2-510](#)
  - enabling [2-218](#)
  - static IP source bindings [2-210](#)
- IP source guard, displaying dynamic binding entries [2-488](#)
- ip ssh command [2-212](#)
- IPv6 access list, deny conditions [2-83](#)
- ipv6 access-list command [2-220](#)
- ipv6 address dhcp command [2-222](#)
- ipv6 dhcp client request vendor command [2-223](#)
- ipv6 dhcp ping packets command [2-224](#)
- ipv6 dhcp pool command [2-225](#)
- ipv6 dhcp server command [2-228](#)
- ipv6 mld snooping command [2-230](#)
- ipv6 mld snooping last-listener-query count command [2-232](#)
- ipv6 mld snooping last-listener-query-interval command [2-234](#)
- ipv6 mld snooping listener-message-suppression command [2-236](#)
- ipv6 mld snooping robustness-variable command [2-237](#)
- ipv6 mld snooping tcn command [2-239](#)
- ipv6 mld snooping vlan command [2-241](#)
- IPv6 SDM template [2-386](#)
- ipv6 traffic-filter command [2-243](#)
- ip verify source command [2-218](#)

---

## J

- jumbo frames
  - See MTU

---

## L

- l2protocol-tunnel command [2-245](#)
- l2protocol-tunnel cos command [2-248](#)



- LACP
  - See EtherChannel
- lacp port-priority command [2-249](#)
- lacp system-priority command [2-251](#)
- Layer 2 mode, enabling [2-679](#)
- Layer 2 protocol ports, displaying [2-521](#)
- Layer 2 protocol-tunnel
  - error detection for [2-118](#)
  - error recovery timer [2-120](#)
- Layer 2 protocol tunnel counters [2-46](#)
- Layer 2 protocol tunneling error recovery [2-247](#)
- Layer 2 traceroute
  - IP addresses [2-722](#)
  - MAC addresses [2-719](#)
- Layer 3 mode, enabling [2-679](#)
- line configuration mode [1-2, 1-4](#)
- Link Aggregation Control Protocol
  - See EtherChannel
- link flap
  - error detection for [2-118](#)
  - error recovery timer [2-120](#)
- link state group command [2-253](#)
- link state track command [2-255](#)
- load-distribution methods for EtherChannel [2-350](#)
- location (global configuration) command [2-256](#)
- location (interface configuration) command [2-258](#)
- logging event command [2-260](#)
- logging file command [2-261](#)
- logical interface [2-145](#)
- loopback error
  - detection for [2-118](#)
  - recovery timer [2-120](#)
- loop guard, for spanning tree [2-638, 2-642](#)
- mac access-list extended command [2-265](#)
- MAC access lists [2-89](#)
- MAC addresses
  - disabling MAC address learning per VLAN [2-268](#)
  - displaying
    - aging time [2-540](#)
    - all [2-539](#)
    - dynamic [2-544](#)
    - MAC address-table move updates [2-549](#)
    - notification settings [2-548, 2-550](#)
    - number of addresses in a VLAN [2-542](#)
    - per interface [2-546](#)
    - per VLAN [2-554](#)
    - static [2-552](#)
    - static and dynamic entries [2-537](#)
  - dynamic
    - aging time [2-267](#)
    - deleting [2-49](#)
    - displaying [2-544](#)
  - enabling MAC address notification [2-272](#)
  - enabling MAC address-table move update [2-270](#)
  - matching [2-285](#)
  - static
    - adding and removing [2-274](#)
    - displaying [2-552](#)
    - dropping on an interface [2-275](#)
  - tables [2-539](#)
- MAC address notification, debugging [B-30](#)
- mac address-table aging-time [2-263, 2-285](#)
- mac address-table aging-time command [2-267](#)
- mac address-table learning command [2-268](#)
- mac address-table move update command [2-270](#)
- mac address-table notification command [2-272](#)
- mac address-table static command [2-274](#)
- mac address-table static drop command [2-275](#)
- macro description command [2-279](#)
- macro global command [2-280](#)
- macro global description command [2-282](#)
- macro name command [2-283](#)

---

## M

- mac access-group command [2-263](#)
- MAC access-groups, displaying [2-536](#)
- MAC access list configuration mode [2-265](#)

## macros

- adding a description [2-279](#)
- adding a global description [2-282](#)
- applying [2-280](#)
- creating [2-283](#)
- displaying [2-566](#)
- interface range [2-78, 2-147](#)
- specifying parameter values [2-280](#)
- tracing [2-280](#)

maintenance end points [2-729](#)

mapping tables, QoS [2-715](#)

## maps

## class

- creating [2-38](#)

## VLAN

- creating [2-738](#)
- defining [2-285](#)
- displaying [2-607](#)

match access-group command [2-287](#)

match cos command [2-288](#)

match dot1ad dei command [2-290](#)

match ip dscp command [2-292](#)

match ip precedence command [2-294](#)

match qos-group command [2-296](#)

match vlan command [2-298](#)

maximum transmission unit

See MTU

mdix auto command [2-301](#)

ME 3400EG-2CS switch policers [C-24](#)

ME 3400E-24TS switch policers [C-24](#)

ME 3400EG-12CS switch policers [C-24](#)

media-type command [2-303](#)

memory (boot loader) command [A-14](#)

mgmt\_clr (boot loader) command [A-15](#)

mgmt\_init (boot loader) command [A-16, A-17](#)

mkdir (boot loader) command [A-18](#)

## MLD snooping

- configuring [2-236, 2-237](#)
- configuring queries [2-232, 2-234](#)
- configuring topology change notification [2-239](#)
- enabling [2-230](#)

MLD snooping on a VLAN, enabling [2-241](#)

mode, MVR [2-309](#)

modes, commands [1-1](#)

monitor session command [2-305](#)

more (boot loader) command [A-19](#)

## MSTP

displaying [2-588](#)

interoperability [2-57](#)

link type [2-640](#)

## MST region

- aborting changes [2-646](#)
- applying changes [2-646](#)
- configuration name [2-646](#)
- configuration revision number [2-647](#)
- current or pending display [2-647](#)
- displaying [2-588](#)
- MST configuration mode [2-646](#)
- VLANs-to-instance mapping [2-646](#)

path cost [2-648](#)

protocol mode [2-644](#)

restart protocol migration process [2-57](#)

## root port

- loop guard [2-638](#)
- preventing from becoming designated [2-638](#)
- restricting which can be root [2-638](#)
- root guard [2-638](#)

## root switch

- affects of extended system ID [2-636](#)
- hello-time [2-651, 2-662](#)
- interval between BDPU messages [2-653](#)
- interval between hello BPDU messages [2-651, 2-662](#)
- max-age [2-653](#)

- maximum hop count before discarding BPDUs [2-655](#)
  - port priority for selection of [2-657](#)
  - primary or secondary [2-662](#)
  - switch priority [2-660](#)
- state changes
  - blocking to forwarding state [2-669](#)
  - enabling BPDU filtering [2-628, 2-666](#)
  - enabling BPDU guard [2-630, 2-666](#)
  - enabling Port Fast [2-666, 2-669](#)
  - forward-delay time [2-650](#)
  - length of listening and learning states [2-650](#)
  - rapid transition to forwarding [2-640](#)
  - shutting down Port Fast-enabled ports [2-666](#)
- state information display [2-587](#)

MTU

- configuring size [2-712](#)
- displaying global setting [2-595](#)

multicast group address, MVR [2-312](#)

multicast groups, MVR [2-310](#)

Multicast Listener Discovery

- See MLD

multicast router learning method [2-202](#)

multicast router ports, configuring [2-202](#)

multicast router ports, IPv6 [2-241](#)

multicast storm control [2-676](#)

multicast VLAN, MVR [2-310](#)

multicast VLAN registration

- See MVR

multiple hosts on authorized port [2-99](#)

Multiple Spanning Tree Protocol

- See MSTP

multiplexing, UNI [2-136](#)

MVR

- and address aliasing [2-310](#)
- configuring [2-309](#)
- configuring interfaces [2-312](#)
- debug messages, display [B-34](#)
- displaying [2-558](#)

- displaying interface information [2-560](#)
  - members, displaying [2-562](#)
- mvr (global configuration) command [2-309](#)
- mvr (interface configuration) command [2-312](#)
- mvr vlan group command [2-313](#)

---

## N

- native VLANs [2-706](#)
- native VLAN tagging [2-740](#)
- network node interface [2-352](#)
- no authentication logging verbose [2-315](#)
- no dot1x logging verbose [2-316](#)
- no mab logging verbose [2-317](#)
- non negotiate, speed [2-674, 2-675](#)
- non-IP protocols
  - denying [2-89](#)
  - forwarding [2-330](#)
- non-IP traffic access lists [2-265](#)
- non-IP traffic forwarding
  - denying [2-89](#)
  - permitting [2-330](#)
- normal-range VLANs [2-735](#)
- no vlan command [2-735](#)

---

## O

- OAM PDUs [2-134](#)
- OAM protocol [2-318](#)
- oam protocol cfm svlan command [2-318](#)
- on-board failure logging, displaying [2-532](#)
- on-board failure logging, enabling [2-143](#)

- online diagnostics
    - enabling
      - scheduling [2-94](#)
    - global configuration mode
      - clearing test-based testing schedule [2-94](#)
      - setting test-based testing [2-94](#)
      - setting up test-based testing [2-94](#)
    - removing scheduling [2-94](#)
    - scheduled switchover
      - disabling [2-94](#)
      - enabling [2-94](#)
    - setting test interval [2-94](#)
    - starting testing [2-96](#)
  - online diagnostic tests, displaying results [2-437](#)
  - online diagnostic tests, starting [2-96](#)
  - operation, administration, and maintenance protocol
    - See OAM
  - output policy maps
    - and QoS group classification [2-296](#)
    - and traffic shaping [2-410](#)
    - commands not supported in [2-348](#)
    - configuration guidelines [2-348](#)
    - priority in [2-357](#)
    - queue limit in [2-364](#)
- 
- P**
- PAGP
    - See EtherChannel
  - pagp learn-method command [2-319](#)
  - pagp port-priority command [2-321](#)
  - parent policy maps [2-395](#)
  - password-recovery mechanism, enabling and disabling [2-391](#)
  - permit (ARP access-list configuration) command [2-323](#)
  - permit (IPv6) command [2-325](#)
  - permit command [2-330](#)
  - per-VLAN spanning-tree plus
    - See STP
  - physical-port learner [2-319](#)
  - PID, displaying [2-482](#)
  - PIM-DVMRP, as multicast router learning method [2-202](#)
  - police
    - multiple conform actions for a class [2-60](#)
    - multiple exceed actions for a class [2-139](#)
    - multiple violate actions for a class [2-733](#)
    - with priority [2-333](#)
  - police aggregate command [2-343](#)
  - police command [2-333](#)
  - policer aggregate command [2-338](#)
  - policer configuration
    - default for NNIs [C-26](#)
    - default for UNIs [C-25](#)
  - policer cpu uni command [2-345](#)
  - policers
    - aggregate [2-338, 2-343](#)
    - for CPU protection [2-345](#)
    - individual [2-333](#)
  - policy-map class, configuring multiple actions [2-60, 2-139, 2-733](#)
  - policy-map class configuration mode [2-36](#)
  - policy-map class police configuration mode [2-60, 2-336](#)
  - policy-map command [2-347](#)
  - policy-map configuration mode [2-347](#)
  - policy maps
    - and CoS classification [2-288](#)
    - and DSCP classification [2-292](#)
    - and IP precedence classification [2-294](#)
    - and policing [2-336](#)
    - applying [2-393](#)
    - applying to an interface [2-348, 2-393, 2-407](#)
    - child [2-395](#)
    - creating [2-347](#)
    - displaying [2-572](#)
    - hierarchical [2-395](#)
    - parent [2-395](#)



**Q**

## QoS

- aggregate policers
    - applying [2-343](#)
    - creating [2-338](#)
    - displaying [2-568](#)
  - class maps
    - creating [2-38](#)
    - defining the match criteria [2-288, 2-290](#)
    - displaying [2-421](#)
  - conform actions, configuring [2-61](#)
  - displaying statistics for [2-572, C-33](#)
  - exceed actions, configuring [2-140](#)
  - policy maps
    - applying an aggregate policer [2-338, 2-343, 2-345, 2-395](#)
    - applying to an interface [2-393, 2-407](#)
    - creating [2-347](#)
    - defining policers [2-333](#)
    - displaying policy maps [2-572](#)
    - setting CoS values [2-397](#)
    - setting DSCP values [2-399, 2-401](#)
    - setting IP precedence values [2-403](#)
    - setting QoS group identifier [2-405](#)
    - traffic classifications [2-36](#)
  - table maps
    - configuring [2-715](#)
    - displaying [2-596](#)
  - violate actions, configuring [2-734](#)
- QoS groups
- as match criteria [2-296](#)
  - for QoS traffic classification [2-405](#)
  - setting in policy maps [2-405](#)
- QoS match criteria
- ACLs [2-287](#)
  - CoS value [2-288](#)
  - DSCP value [2-292, 2-298](#)
  - precedence value [2-294](#)

- QoS group number [2-296](#)
- quality of service
  - See QoS
- querytime, MVR [2-309](#)
- queue-limit command [2-364](#)

**R**

- rapid per-VLAN spanning-tree plus
  - See STP
- rapid PVST+
  - See STP
- re-authenticating 802.1x-enabled ports [2-107](#)
- re-authentication
  - periodic [2-108](#)
  - time between attempts [2-113](#)
- receiver ports, MVR [2-312](#)
- receiving flow-control packets [2-141](#)
- recovery mechanism
  - causes [2-120](#)
  - display [2-419, 2-447, 2-451](#)
  - timer interval [2-121](#)
- remote-span command [2-367](#)
- Remote Switched Port Analyzer
  - See RSPAN
- rename (boot loader) command [A-20](#)
- renew ip dhcp snooping database command [2-369](#)
- rep admin vlan command [2-370](#)
- rep block port command [2-371](#)
- rep lsl-age-timer command [2-375](#)
- rep preempt delay command [2-377](#)
- rep preempt segment command [2-379](#)
- rep segment command [2-380](#)
- rep stcn command [2-383](#)
- reset (boot loader) command [A-21](#)
- resource templates, displaying [2-585](#)
- rmdir (boot loader) command [A-22](#)
- rmon collection stats command [2-385](#)
- root guard, for spanning tree [2-638](#)

## routed ports

- IP addresses on [2-155](#)
- number supported [2-155](#)

## RSPAN

- configuring [2-305](#)
- displaying [2-556](#)
- filter RSPAN traffic [2-305](#)
- remote-span command [2-367](#)
- sessions
  - add interfaces to [2-305](#)
  - displaying [2-556](#)
  - start new [2-305](#)

---

**S**

## scheduled switchover

- disabling [2-94](#)
- enabling [2-94](#)

scheduling diagnostic tests [2-94](#)sdm prefer command [2-386](#)

## SDM templates

- allowed resources [2-387](#)
- displaying [2-585](#)
- dual IPv4 and IPv6 [2-386](#)

secure ports, limitations [2-698](#)sending flow-control packets [2-141](#)service instance command [2-389](#)service instances, displaying [2-459](#)service password-recovery command [2-391](#)service policy (policy-map class configuration) command [2-395](#)service-policy interface configuration command [2-393](#)service-policy policy-map class configuration command [2-395](#)set (boot loader) command [A-23](#)set cos command [2-397](#)set dot1ad dei command [2-399](#)set dscp command [2-401](#)set precedence command [2-403](#)set qos-group command [2-405](#)setup command [2-407](#)SFPs, displaying information about [2-482](#)shape average command [2-410](#)show access-lists command [2-412](#)show aggregate-policer command [2-595](#)show archive status command [2-415](#)show arp access-list command [2-416](#)show boot command [2-417](#)show class-map command [2-421](#)show controllers cpu-interface command [2-422](#)show controllers ethernet-controller command [2-424](#)show controllers tcam command [2-431](#)show controllers utilization command [2-433](#)show controller utilization command [2-433](#)show cpu traffic qos command [2-435](#)show diagnostic command [2-437](#)show dot1q-tunnel command [2-441](#)show dot1x command [2-442](#)show env command [2-445](#)show errdisable detect command [2-447](#)show errdisable flap-values command [2-449](#)show errdisable recovery command [2-451](#)show etherchannel command [2-453](#)show ethernet loopback command [2-456](#)show ethernet service evc command [2-458](#)show ethernet service instance command [2-459](#)show ethernet service interface command [2-461](#)show flowcontrol command [2-463](#)show idprom command [2-465](#)show interface rep command [2-477](#)show interfaces command [2-467](#)show interfaces counters command [2-475](#)show interfaces rep command [2-477](#)show interface transceivers command [2-479](#)show inventory command [2-482](#)show ip arp inspection command [2-483](#)show ipc command [2-512](#)show ip dhcp snooping binding command [2-488](#)

- show ip dhcp snooping command [2-487](#)
- show ip dhcp snooping database command [2-490, 2-492](#)
- show ip igmp profile command [2-497](#)
- show ip igmp snooping command [2-498](#)
- show ip igmp snooping command querier detail [2-503](#)
- show ip igmp snooping groups command [2-500](#)
- show ip igmp snooping mrouter command [2-502](#)
- show ip igmp snooping querier command [2-503](#)
- show ip igmp snooping querier detail command [2-503](#)
- show ip sla standards command [2-505](#)
- show ip sla twamp connection [2-435](#)
- show ip sla twamp connection command [2-506](#)
- show ip sla twamp session command [2-508](#)
- show ip source binding command [2-509](#)
- show ipv6 access-list command [2-516](#)
- show ipv6 dhcp conflict command [2-518](#)
- show ipv6 route updated command [2-519](#)
- show ip verify source command [2-510](#)
- show l2protocol-tunnel command [2-521](#)
- show lacp command [2-523](#)
- show link state group command [2-527](#)
- show location command [2-529](#)
- show logging onboard command [2-532](#)
- show mac access-group command [2-536](#)
- show mac address-table address command [2-539](#)
- show mac address-table aging time command [2-540](#)
- show mac address-table command [2-537](#)
- show mac address-table count command [2-542](#)
- show mac address-table dynamic command [2-544](#)
- show mac address-table interface command [2-546](#)
- show mac address-table learning command [2-548](#)
- show mac address-table move update command [2-549](#)
- show mac address-table notification command [2-50, 2-550, B-32](#)
- show mac address-table static command [2-552](#)
- show mac address-table vlan command [2-554](#)
- show monitor command [2-556](#)
- show mvr command [2-558](#)
- show mvr interface command [2-560](#)
- show mvr members command [2-562](#)
- show pagp command [2-564](#)
- show parser macro command [2-566](#)
- show platform acl command [C-2](#)
- show platform backup interface command [C-3](#)
- show platform cfm command [C-4](#)
- show platform configuration command [C-5](#)
- show platform dl command [C-6](#)
- show platform etherchannel command [C-7](#)
- show platform forward command [C-8](#)
- show platform frontend-controller command [C-10](#)
- show platform igmp snooping command [C-11](#)
- show platform ipc trace command [C-14](#)
- show platform ip multicast command [C-12](#)
- show platform ip unicast command [C-13](#)
- show platform ipv6 unicast command [C-15](#)
- show platform l2pt dm command [C-17](#)
- show platform layer4op command [C-18, C-40](#)
- show platform mac-address-table command [C-19](#)
- show platform messaging command [C-20](#)
- show platform monitor command [C-21](#)
- show platform mvr table command [C-22](#)
- show platform pm command [C-23](#)
- show platform policer cpu command [C-24](#)
- show platform port-asic command [C-28](#)
- show platform port-security command [C-32](#)
- show platform qos command [C-33](#)
- show platform resource-manager command [C-36](#)
- show platform snmp counters command [C-38](#)
- show platform spanning-tree synchronization command [C-39](#)
- show platform stp-instance command [C-41](#)
- show platform team command [C-42](#)
- show platform vlan command [C-44](#)
- show platform vlan mapping command [C-45](#)
- show policer aggregate command [2-568](#)
- show policer cpu uni-eni command [2-569](#)
- show policy-map command [2-572](#)
- show policy-map interface output fields [2-575](#)



- show port security command [2-577](#)
- show port-type command [2-580](#)
- show rep topology command [2-582](#)
- show sdm prefer command [2-585](#)
- show spanning-tree command [2-587](#)
- show storm-control command [2-593](#)
- show system mtu command [2-595](#)
- show udd command [2-597](#)
- show version command [2-600](#)
- show vlan access-map command [2-607](#)
- show vlan command [2-602](#)
- show vlan command, fields [2-604](#)
- show vlan filter command [2-608](#)
- show vlan mapping command [2-609](#)
- show vmps command [2-611](#)
- shutdown command [2-613](#)
- shutdown threshold, Layer 2 protocol tunneling [2-245](#)
- shutdown vlan command [2-614](#)
- SNMP host, specifying [2-620](#)
- SNMP informs, enabling the sending of [2-616](#)
- snmp mib rep trap-rate command [2-615](#)
- snmp-server enable traps command [2-616](#)
- snmp-server host command [2-620](#)
- snmp trap mac-notification change command [2-624](#)
- SNMP traps
  - enabling MAC address notification trap [2-624](#)
  - enabling the MAC address notification feature [2-272](#)
  - enabling the sending of [2-616](#)
- software images
  - deleting [2-80](#)
  - downloading [2-9](#)
  - upgrading [2-9](#)
  - uploading [2-15](#)
- software version, displaying [2-600](#)
- source ports, MVR [2-312](#)
- SPAN
  - configuring [2-305](#)
  - debug messages, display [B-33](#)
  - displaying [2-556](#)
  - filter SPAN traffic [2-305](#)
  - sessions
    - add interfaces to [2-305](#)
    - displaying [2-556](#)
    - start new [2-305](#)
  - spanning-tree bpdudfilter command [2-626, 2-628](#)
  - spanning-tree bpduguard command [2-630](#)
  - spanning-tree cost command [2-632](#)
  - spanning-tree etherchannel command [2-634](#)
  - spanning-tree extend system-id command [2-636](#)
  - spanning-tree guard command [2-638](#)
  - spanning-tree link-type command [2-640](#)
  - spanning-tree loopguard default command [2-642](#)
  - spanning-tree mode command [2-644](#)
  - spanning-tree mst configuration command [2-646](#)
  - spanning-tree mst cost command [2-648](#)
  - spanning-tree mst forward-time command [2-650](#)
  - spanning-tree mst hello-time command [2-651](#)
  - spanning-tree mst max-age command [2-653](#)
  - spanning-tree mst max-hops command [2-655](#)
  - spanning-tree mst port-priority command [2-657](#)
  - spanning-tree mst pre-standard command [2-659](#)
  - spanning-tree mst priority command [2-660](#)
  - spanning-tree mst root command [2-662](#)
  - spanning-tree portfast (global configuration) command [2-666](#)
  - spanning-tree portfast (interface configuration) command [2-669](#)
  - spanning-tree port-priority command [2-664](#)
  - Spanning Tree Protocol
    - See STP
  - spanning-tree vlan command [2-671](#)
  - speed command [2-674](#)
  - SSH, configuring version [2-212](#)
  - static-access ports, configuring [2-681](#)
  - statistics, Ethernet group [2-385](#)

- sticky learning, enabling [2-696](#)
  - storm-control command [2-676](#)
  - STP
    - counters, clearing [2-56](#)
    - debug messages, display
      - MSTP [B-88](#)
      - optimized BPDUs handling [B-87](#)
      - spanning-tree activity [B-84](#)
      - switch shim [B-90](#)
      - transmitted and received BPDUs [B-86](#)
    - enabling on ENIs [2-626](#)
    - enabling protocol tunneling for [2-245](#)
    - EtherChannel misconfiguration [2-634](#)
    - extended system ID [2-636](#)
    - path cost [2-632](#)
    - protocol modes [2-644](#)
    - root port
      - loop guard [2-638](#)
      - preventing from becoming designated [2-638](#)
      - restricting which can be root [2-638](#)
      - root guard [2-638](#)
    - root switch
      - affects of extended system ID [2-636, 2-672](#)
      - hello-time [2-671](#)
      - interval between BDPUs messages [2-671](#)
      - interval between hello BDPUs messages [2-671](#)
      - max-age [2-671](#)
      - port priority for selection of [2-664](#)
      - primary or secondary [2-671](#)
      - switch priority [2-671](#)
    - state changes
      - blocking to forwarding state [2-669](#)
      - enabling BDPUs filtering [2-628, 2-666](#)
      - enabling BDPUs guard [2-630, 2-666](#)
      - enabling Port Fast [2-666, 2-669](#)
      - enabling timer to recover from error state [2-120](#)
      - forward-delay time [2-671](#)
      - length of listening and learning states [2-671](#)
      - shutting down Port Fast-enabled ports [2-666](#)
      - state information display [2-587](#)
      - VLAN options [2-660, 2-671](#)
    - SVIs, creating [2-149](#)
    - Switched Port Analyzer
      - See SPAN
    - switching characteristics
      - modifying [2-679](#)
      - returning to interfaces [2-679](#)
    - switchport access command [2-681](#)
    - switchport backup interface command [2-683](#)
    - switchport block command [2-687](#)
    - switchport command [2-679](#)
    - switchport host command [2-689](#)
    - switchport mode command [2-690](#)
    - switchport mode private-vlan command [2-693](#)
    - switchport port-security aging command [2-700](#)
    - switchport port-security command [2-696](#)
    - switchport private-vlan command [2-702](#)
    - switchport protected command [2-704](#)
    - switchports, displaying [2-467](#)
    - switchport trunk command [2-706](#)
    - switchport vlan mapping command [2-708](#)
    - system env temperature threshold yellow command [2-711](#)
    - system message logging, save message to flash [2-261](#)
    - system mtu command [2-712](#)
    - system resource templates [2-386](#)
- 
- ## T
- table-map command [2-715](#)
  - table-map configuration mode [2-715](#)
  - table maps
    - configuring [2-715](#)
    - displaying [2-596](#)
    - QoS [2-715](#)
  - tar files, creating, listing, and extracting [2-12](#)
  - TDR, running [2-717](#)
  - temperature information, displaying [2-445](#)
  - temperature status, displaying [2-445](#)

templates, system resources [2-386](#)  
 test cable-diagnostics tdr command [2-717](#)  
 traceroute mac command [2-719](#)  
 traceroute mac ip command [2-722](#)  
 traffic shaping, QoS [2-410](#)  
 trunking, VLAN mode [2-690](#)  
 trunk mode [2-690](#)  
 trunk ports [2-690](#)  
 tunnel ports, Layer 2 protocol, displaying [2-521](#)  
 type (boot loader) command [A-26](#)

## U

### UDLD

aggressive mode [2-724, 2-726](#)  
 debug messages, display [B-96](#)  
 enable globally [2-724](#)  
 enable per interface [2-726](#)  
 error recovery timer [2-120](#)  
 message timer [2-724](#)  
 normal mode [2-724, 2-726](#)  
 reset a shutdown interface [2-728](#)  
 status [2-597](#)  
 udd command [2-724](#)  
 udd port command [2-726](#)  
 udd reset command [2-728](#)

### UNI

bundling and multiplexing [2-136](#)  
 Ethernet [2-136](#)  
 unicast storm control [2-676](#)  
 uni count command [2-729](#)

### UniDirectional Link Detection

See UDLD

UNI ID, Ethernet [2-138](#)  
 uni-vlan command [2-731](#)  
 unknown multicast traffic, preventing [2-687](#)  
 unknown unicast traffic, preventing [2-687](#)  
 unset (boot loader) command [A-27](#)

upgrading  
     software images [2-9](#)  
         monitoring status of [2-415](#)  
 user EXEC mode [1-2](#)  
 user network interface [2-352](#)

## V

version (boot loader) command [A-29](#)  
 violate-action command [2-733](#)  
 vlan access-map command [2-738](#)  
 VLAN access map configuration mode [2-738](#)  
 VLAN access maps  
     actions [2-5](#)  
     displaying [2-607](#)  
 vlan command [2-735](#)  
 VLAN configuration mode  
     commands [2-735](#)  
     description [1-4](#)  
     entering [2-735](#)  
     summary [1-2](#)  
 vlan dot1q tag native command [2-740](#)  
 vlan filter command [2-742](#)  
 VLAN filters, displaying [2-608](#)  
 VLAN ID range [2-735](#)  
 VLAN ID translation  
     See VLAN mapping  
 VLAN mapping  
     configuring [2-708](#)  
     described [2-709](#)  
     displaying [2-609](#)  
 VLAN maps  
     applying [2-742](#)  
     creating [2-738](#)  
     defining [2-285](#)  
     displaying [2-607](#)  
 VLAN Query Protocol  
     See VQP

## VLANs

- adding [2-735](#)
- configuring [2-735](#)
- debug messages, display
  - activation of [B-94](#)
  - VLAN IOS file system error tests [B-93](#)
  - VLAN manager activity [B-92](#)
- displaying configurations [2-602](#)
- extended-range [2-735](#)
- MAC addresses
  - displaying [2-554](#)
  - number of [2-542](#)
- normal-range [2-735](#)
- private [2-693](#)
  - configuring [2-359](#)
  - displaying [2-602](#)
  - See also private VLANs
- restarting [2-614](#)
- saving the configuration [2-735](#)
- shutting down [2-614](#)
- suspending [2-614](#)

## VMPS

- configuring servers [2-747](#)
- displaying [2-611](#)
- error recovery timer [2-121](#)
- reconfirming dynamic VLAN assignments [2-744](#)
- vmmps reconfirm (global configuration) command [2-745](#)
- vmmps reconfirm (privileged EXEC) command [2-744](#)
- vmmps retry command [2-746](#)
- vmmps server command [2-747](#)

## VQP

- and dynamic-access ports [2-682](#)
- clearing client statistics [2-59](#)
- displaying information [2-611](#)
- per-server retry count [2-746](#)
- reconfirmation interval [2-745](#)
- reconfirming dynamic VLAN assignments [2-744](#)

## VTP

- enabling
  - tunneling for [2-245](#)

---

**W**

## Weighted Tail Drop

See WTD

WTD, queue-limit command [2-364](#)