



# Sample VNF Rack and VNF Descriptor Configuration File

---

As described in [Configure the VNF Rack and the VNF Descriptors](#), VNF rack configuration parameters are contained in the VIM Artifact Descriptor (VIM-ArtifactD) while VNF configuration parameters are contained in the VNF descriptor (VNFD).



**Caution**

This is only a sample configuration file provided solely for your reference. You must create and modify your own configuration file according to the specific needs of your deployment.

---

